

Demonstration kit for the ST7570 power line modem with graphical user interface


Introduction

The ST7570 GUI is a software tool that allows interfacing with one or more STMicroelectronics™ power line modem (PLM) demonstration boards with a personal computer (PC). Only PLM demonstration boards equipped with the ST7570 device are supported.

The ST7570 GUI gives the user complete control of the ST7570 device, having access to all its registers and functions, as described in [2].

The typical application environment (shown in [Figure 1](#)) consists of an ST7570 GUI running on a PC and communicating through a USB connection with a PLM demonstration kit equipped with the ST7570 product, such as the EVALKITST7570-1 (consisting of a modem board and a power supply board).

Figure 1. ST7570 typical application environment



Contents

- 1 Document conventions 4**
- 2 Connection procedure 5**
- 3 GUI installation 9**
 - 3.1 System requirements 9
 - 3.2 Installing the software 9
- 4 Getting started 12**
 - 4.1 Introduction 12
 - 4.2 Adding other nodes 13
 - 4.3 Opening the COM 14
- 5 Services 17**
 - 5.1 Basic modem configuration 17
 - 5.2 PHY layer communication 18
 - 5.2.1 Synchro indication information 19
 - 5.2.2 PHY data indication information 19
 - 5.2.3 Synchronization management 20
 - 5.3 MIB operations 22
 - 5.4 MAC layer communication 24
 - 5.4.1 MAC frame transmission 24
 - 5.4.2 Synchro indication found information 25
 - 5.4.3 MAC data indication information 25
 - 5.4.4 Synchronization management notification 25
 - 5.4.5 Statistic information 26
 - 5.5 Alarm services 26
 - 5.6 Repeater Call 27
 - 5.6.1 Repeater Call for client nodes 28
 - 5.6.2 Repeater Call for server nodes 28
- 6 References 30**
- 7 Revision history 31**

List of figures

Figure 1. ST7570 typical application environment 1

Figure 2. Hardware update wizard screen 5

Figure 3. New hardware update wizard 6

Figure 4. Found new hardware update wizard 6

Figure 5. Hardware installation 7

Figure 6. Software installation 7

Figure 7. Completing the found new hardware update wizard 8

Figure 8. ST7570 GUI installation wizard 9

Figure 9. ST7570 GUI setup 10

Figure 10. Application installation 10

Figure 11. Application installed 11

Figure 12. ST7570 GUI main window 12

Figure 13. ST7570 GUI tooltip example 13

Figure 14. "Add node" procedure to add a new node 13

Figure 15. The new node has been added - (panel Node 2) is now available 13

Figure 16. Modem connection procedure 14

Figure 17. Modem connection success 14

Figure 18. Start the automatic COM port number detection procedure 15

Figure 19. Automatic COM port number detection procedure: step 1 15

Figure 20. Automatic COM port number detection procedure: step 2 15

Figure 21. Automatic COM port number detection procedure: final step 16

Figure 22. Modem configuration 17

Figure 23. PHY power line transmission 18

Figure 24. Communication notifications 18

Figure 25. Synchro Indication information 19

Figure 26. Data indication information 20

Figure 27. Synchronization status information 21

Figure 28. Synchronization reject request command 21

Figure 29. MIB parameter panel default appearance 22

Figure 30. MAC layer configuration parameters 23

Figure 31. MIB object writing and reading 23

Figure 32. MIB object writing and reading: console messages 23

Figure 33. MAC layer frame composition 24

Figure 34. MAC communication notifications 24

Figure 35. Synchro indication found information 25

Figure 36. Data indication information 25

Figure 37. Synchro indication lost information 25

Figure 38. MAC statistic information counters 26

Figure 39. Alarm service settings 26

Figure 40. Alarm service notifications 27

Figure 41. Alarm counters controls 27

Figure 42. RC request catch setting 27

Figure 43. Repeater Call request for client 28

Figure 44. Repeater settings for server node 28

Figure 45. RC confirm for server node 29

1 Document conventions

The following abbreviations are used:

Table 1. List of abbreviations

Abbreviation	Description
PRE	Preamble
SSD	Start of Subframe Delimitation
MIB	Management Information Base
PGA	Programmable Gain Amplifier
ZC	Zero-crossing
PHY	Physical Layer
MAC	Medium Access Layer
DA	Destination Address
SA	Source Address
NS	Number of Subframes
FCS	Frame Check Sequence
CRC	Cyclic Redundancy Check
M_sdu	MAC service data unit
M_pdu	MAC protocol data unit
IC	Initial Credit
CC	Current Credit
DC	Delta Credit
TIC	Inter-character Timeout
FIMA	First Initiator MAC Address
LIMA	Last Initiator MAC Address
RC	Repeater call procedure
IS	Intelligent Synchronization procedure

2 Connection procedure

In order to connect EVALKITST7570-1 to the PC, the user must follow the instructions below:

1. Connect the board to the PC using a USB cable.
2. Plug a power cable into the board AC power plug.
3. Plug the power cable into the power socket.
4. As soon as the board is powered, the power LEDs switch on.


USB/UART adapter driver installation

The USB communication between the EVALKITST7570-1 and the PC is managed through an onboard USB to UART adapter. This device needs the installation of the correct device software driver on the PC.

Assuming that the device drivers are not yet installed, follow the instructions below:


1. Download the latest available Virtual COM Port (VCP) drivers from the FTDI web site (www.ftdichip.com) and unzip them to a location on the host PC.
2. Connect the EVALKITST7570-1 to a spare USB port on the host PC. The screen shown in [Figure 2](#) is displayed. Select “No, not this time” from the options available and then click “Next” to proceed with the installation.

Figure 2. Hardware update wizard screen




3. Select "Install from a list or specific location (Advanced)", as shown in *Figure 3* below and then click "Next".

Figure 3. New hardware update wizard



4. Select "Search for the best driver in these locations" and enter the file path in the combo-box ("C:\CDM 2.02.04", in the example shown in *Figure 4*) or browse to it by clicking "Browse". Once the file path has been entered in the box, click "Next" to proceed.

Figure 4. Found new hardware update wizard




5. If Windows® XP is configured to warn when unsigned (non-WHQL certified) drivers are about to be installed, the message dialogue shown in [Figure 5](#) is displayed, unless installing a Microsoft® WHQL certified driver. Click on “Continue Anyway” to continue with the installation. If Windows XP is configured to ignore file signature warnings, no message appears.

Figure 5. Hardware installation




6. The screen shown in [Figure 6](#) is displayed as Windows XP copies the required driver files.

Figure 6. Software installation



7. A message should then appear indicating that the installation was successful (*Figure 7*). Click “Finish” to complete the installation for the first port of the device.

Figure 7. Completing the found new hardware update wizard



Once the driver installation is complete a new “USB serial port” device is installed on the host PC.

3 GUI installation

3.1 System requirements

A personal computer (PC) including:

- Windows NT/2000/XP operating system
- A hard disk with at least 15 MBytes of free space to install the GUI
- One or more USB 1.1 ports

3.2 Installing the software

Follow the instructions below to install the ST7570 GUI software.


1. Extract the contents of the archive in a new directory.
2. Launch “setup.exe” to start the install procedure.
3. Press the “Next” button (*Figure 8*).

Figure 8. ST7570 GUI installation wizard




4. Choose an installation path (the default path is suggested) and press the “Next” button (*Figure 9*).

Figure 9. ST7570 GUI setup



5. Press the “Next” button to start the installation (*Figure 10*).

Figure 10. Application installation



- Once installation has completed, press the “Finish” button to complete the process ([Figure 11](#)).

Figure 11. Application installed



4 Getting started

4.1 Introduction


The ST7570 GUI gives the user complete control of the ST7570 device, with full access to all the settings and functions described in [1]. The GUI can be used to:

- Establish a connection to the ST7570 modem
- Configure the ST7570 and manage all its settings
- Perform any transmission and reception of data and alarms over the power line

Figure 12 shows the main window of the ST7570 GUI. The panel is divided into two sections:


1. Node panel: used to control an ST7570 node. In case of multiple nodes connected to the GUI, the user can switch between the panels through the node panel tabs.
2. Console: box displaying where all the messages exchanged with the node are displayed. In the case of multiple nodes, this panel is common to all the nodes.

Figure 12. ST7570 GUI main window



Almost all graphical interface objects and relative controls show their tooltips, when the user hovers the cursor over this item: these tooltips give information about the meaning and the use of the controls and parameters.

Figure 13. ST7570 GUI tooltip example




AM10504v1

4.2 Adding other nodes

By default, the GUI shows only one node tab in the panel ("Node 1" in [Figure 12](#)). Nevertheless, a single instance of the ST7570 GUI can control more nodes if needed. To add a new node, left-click on the "Main" menu and then select the menu item "Add node" ([Figure 14](#)).


Figure 14. "Add node" procedure to add a new node



AM10505v1

As a result, a new panel tab appears (with tab "Node 2" in [Figure 15](#)).

Figure 15. The new node has been added - (panel Node 2) is now available




AM10506v1

4.3 Opening the COM

To establish communication with the ST7570 demonstration board:


1. Automatically identify or manually select the COM port number associated to the board
2. Select the desired baud rate. Note that modem boards come with a factory default baud rate equal to 57600 bps.

Figure 16. Modem connection procedure



If the connection is properly established, the light switches to green and a positive notification is displayed on the console:


Figure 17. Modem connection success



Automatic COM port number detection


This guided procedure allows the user to simply identify the COM port number related to the board they would like to connect with. As indicated in *Figure 18*, the “Identify COM” button in the node panel must be pressed:

Figure 18. Start the automatic COM port number detection procedure




First of all, the procedure invites the user to remove the desired modem's USB cable:

Figure 19. Automatic COM port number detection procedure: step 1




Then the user should plug in the USB cable:

Figure 20. Automatic COM port number detection procedure: step 2



The automatic procedure stops communicating the detected COM number and sets this value in the relative control:

Figure 21. Automatic COM port number detection procedure: final step



AM10510v1

5 Services

5.1 Basic modem configuration

At power-on, the modem is in IDLE state (refer to [2]).


In order to perform communication on the power line, the modem must be configured through the “Configure” button.

This command groups all the basic operating settings of the modem, as resumed in MIB 0x00A1 object (“PLC Configuration”):

- Operating mode
- Bit rate
- Mains frequency
- Transmission gain
- Channel frequencies
- Access layer mode
- Current control


A confirmation (positive or negative) appears on the console notifying that either the configuration required has been successfully set or an error has occurred (Figure 22).

Figure 22. Modem configuration



In PHY operating mode, these are all the configuration settings needed to perform transmission and reception on the power line.

Figure 26. Data indication information



AM10515v1

5.2.3 Synchronization management


A client modem acquires the timeslot synchronization as soon as a frame is either transmitted or received; a server node is not allowed to transmit if not synchronized, and synchronization can be achieved through a valid reception only.

CMD_SynchroStatus

In the Node tab, the CMD_SynchroStatus button can be used to know the synchronization status of the modem, as it implements the CMD_SynchroStatus command [2].

Both console and “Sync” box show the modem status: Found(1) or NotFound(2) are the possible answers, as in [Figure 27](#).

Figure 27. Synchronization status information




AM10516v1

CMD_DesynchroRequest

It is possible to force a rejection of the synchronization through the dedicated command CMD_DesynchroRequest. When pressed, the CMD_DesynchroRequest button in the node tab allows this request to be sent. The execution of this command does not generate any answer notification and, therefore, the console does not show any message.

Figure 28. Synchronization reject request command




5.3 MIB operations

In addition to basic modem configuration, explained in [Section 6.1](#), as described in the IEC61334-5-1 standard, there are several other parameters that influence modem behavior when configured as MAC; all these parameters belong to the MIB and are accessible through MIB write and read operations.

[Figure 29](#) shows the panel that appears once the “MIB” button in the node panel is pressed.

Figure 29. MIB parameter panel default appearance




The MIB parameters allowing basic operations at MAC layer are:

1. Addresses: Local MAC address, Initiator MAC address, FIMA and LIMA, and MAC group addresses.
2. Timeout: Time Out Synchro Confirm[sec], Not OK[sec], Not Addressed[min] and Intelligent Synchronization[min].
3. Repeater settings: (for server only).

[Figure 29](#) shows their position in the “MIB” panel.


Figure 30. MAC layer configuration parameters



The MIB panel allows to write and read all the MIB objects listed and described in [2]. The object name used in the label is the same as in [2.] and the object index is shown on the tooltip.


For all MIB objects, the “W” button close to the corresponding box name allows to write the value set in the box in the ST7570 registers. On the other hand, the “R” button reports the current value stored in the ST7570 registers and it is displayed in the corresponding box name.

Figure 31. MIB object writing and reading



The GUI console displays the result of both operations, as in Figure 32:

Figure 32. MIB object writing and reading: console messages




5.4.5 Statistic information

Several MIB variables (accessible through indexed MIB write and read operations) allow a complete analysis of the communicating behavior and performance of the modem set in MAC mode.

The writing operation on these statistic variables causes a reset to default values and the Reset Count's button resets all the counter values.

Figure 38. MAC statistic information counters




5.5 Alarm services

Once synchronized, the node can transmit, receive, and repeat alarms according to the settings stored in the following MIB objects:


1. Alarm Repetition number, Alarm Before Indication number, Alarm Reject Window number: MIB object 0085h in [2].
2. Disable Alarm Indication, Disable Alarm Repetition, Disable Alarm SN Indication: MIB object 0086h in [2].

Figure 39. Alarm service settings



In case of alarm transmission, the console displays the successful Alarm Confirm notification in the client side and the Alarm Indication notification with the total number of received alarms in the server side.


Figure 40. Alarm service notifications



AM10524v1

Through MIB alarm counters (MIB object 0083h, 0084h in [2.]), it is also possible to know the total number of transmitted and received alarms (these values depend on the alarm setting):


Figure 41. Alarm counters controls



5.6 Repeater Call

The ST7570 GUI allows the user to manage the Repeater Call for both MAC Client and Server nodes. In order to activate the automatic recognition of the Repeater Call procedure, the “RC Request Catch” setting must be ticked as in [Figure 42](#).

Figure 42. RC request catch setting




AM10525v1

5.6.1 Repeater Call for client nodes

The Repeater Call service is started by a Client node in accordance with the details presented in [2]. By pressing the CMD_RC Request button with the parameters presented in Figure 43 properly filled, the GUI performs both operations:

- send a MAC data request command to the connected modem following the upper protocol layer specifications for Data Payload; the Payload window automatically switches to the RC Request (BASIC) item; the data transmission takes into account the credit parameters expressed in the GUI (the IC parameter must be greater than 0 so that the modem can accept the RC Request)
- send an RC Request to the modem while powerline transmission is in progress to respect the RC mechanism, with the TX_POS, RC_THRESHOLD parameters expressed in the GUI.


Figure 43. Repeater Call request for client



5.6.2 Repeater Call for server nodes

In order to activate the Repeater Call service for server nodes, the MIB object 000Bh (repeater settings) must be written to either a “No” or “Yes” value through the referred ring menu from the MIB panel, as in Figure 44.

Figure 44. Repeater settings for server node



After a valid reception of a MAC frame properly filled to announce the Repeater Call mechanism (as the one sent by the Client in Section 5.6.1), if the Server receives an RC

pattern during the next timeslot, the GUI console displays the RC Confirm with all its parameters:

Figure 45. RC confirm for server node

```
* 11:19:48 * 08/03 * COM8 *** TAG 0x62, LENGTH 13
NODE 2 (COM8) --- PKT 000001: CMD_RCConfirm 0xff (LP_OK) 0x03 (REPEATER) S: 11416, N: 9173, RC_RxPosition: 0xffff
```

AM10528v1

6 References

1. STMicroelectronics, ST7570; *S-FSK power line networking system-on-chip*, datasheet
2. STMicroelectronics, UM0934; *FSK, PSK Multi-Mode Power Line Networking System On Chip*, user manual
3. International Electrotechnical Commission (IEC), IEC 61334-5-1 ed2.0, www.iec.ch

7 Revision history

Table 2. Document revision history

Date	Revision	Changes
22-Nov-2010	1	Initial release.
04-Nov-2011	2	– Modified: Table 1 – Changed: Figure 12, 13, 14, 15, 16, 17, 18, 21, 22, 23, 24, 25, 26, 27, 30, 31, 32, 34, 35, 36, 37 and 40 – Added: Section 5.6

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY TWO AUTHORIZED ST REPRESENTATIVES, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2011 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com