


# TMC8462A-EVAL

Document Revision V1.20 • 2022-Sept-05


**The TMC8462A-EVAL is designed for evaluating all features of the TMC8462A-BA EtherCAT Slave Controller. It can be used as bus interface module for EtherCAT applications.**



## Applications

- Laboratory Automation
- Drives
- Semiconductor Handling
- Robotics
- Factory Automation
- Connected Sensors

## Simplified Block Diagram



©2022 TRINAMIC Motion Control GmbH & Co. KG, Hamburg, Germany  
Terms of delivery and rights to technical change reserved.  
Download newest version at: [www.trinamic.com](http://www.trinamic.com)



## Contents

<b>1 Getting Started</b>	<b>3</b>
1.1 First Start-Up . . . . .	4
<b>2 Evaluation Board Sections and Components</b>	<b>6</b>
2.1 Evaluation Board Connectors . . . . .	6
2.2 Evaluation Board Pin Headers . . . . .	6
2.3 Evaluation Board Jumper Settings . . . . .	8
<b>3 Evaluation Board Design Files</b>	<b>11</b>
<b>4 Example XML File</b>	<b>11</b>
<b>5 Revision History</b>	<b>14</b>
5.1 Document Revision . . . . .	14

## 1 Getting Started

### You need

- TMC8462A-EVAL
- TRINAMIC's [Landungsbruecke](#)
- Firmware for [Landungsbruecke](#) with simple implementation of the ESM (EtherCAT State Machine)
- Eselsbruecke connector board
- Power Supply 5V-35V for the evaluation board itself
- Latest [TMCL-IDE](#)
- RJ45 network cables and additional cables you need for your setup
- EtherCAT master system (Beckhoff TwinCAT, SOEM, Omron, Ancosys...)

### Precautions

- Do not mix up connections or short-circuit pins.
- Do not exceed the maximum rated supply supply voltage!
- START WITH POWER SUPPLY OFF!




Figure 1: TMC8462A-EVAL kit with [Landungsbruecke](#), [Eselsbruecke](#) and TMC8462A-EVAL

#### NOTICE

The Landungsbruecke operates on USB Power Supply. All other voltages are generated from the evaluation board supply 5V-35V. The kit works only when both supplies are connected.

## 1.1 First Start-Up

1. Make sure that the latest version of the TMCL-IDE is installed. The TMCL-IDE can be downloaded from [www.trinamic.com/support/software/tmcl-ide/](http://www.trinamic.com/support/software/tmcl-ide/).
2. Open the TMCL-IDE and connect the Landungsbruecke via USB to the computer. For Windows 10 no extra USB driver needed. On Windows 7 and 8 machines the TMCL-IDE can install the driver automatically.
3. Verify that the Landungsbruecke is using the latest firmware version. The firmware version is shown in the connected device tree. The latest firmware is always available online at <https://www.trinamic.com/support/kits/details/landungsbruecke/>




Figure 2: Firmware Version

4. The TMCL-IDE needs room to show all important information and to provide a good overview. Therefore, arrange the main window related to your needs. We recommend using full screen.




Figure 3: Landungsbruecke Dialogue

5. The TMCL-IDE includes a dialogue for diagnostic tasks for the controller board. Further, the dialogue provides an overview of the connected evaluation board (controller and/or driver). The TMC8462-EVAL should appear under "controller" by automatic detection. In case it does not appear, the evaluation board can also be selected manually. A window should pop up immediately after connecting the evaluation kit the first time. The window shows the general status of the connected evaluation

board. The second tab of the dialogue offers the possibility to choose basic settings or to reset the module.

6. If not yet done also connect your Ethernet TPC cables into the RJ45 bus connections of the TMC8462A-EVAL to connect to other EtherCAT slaves and your EtherCAT master system.
7. For operation with the Landungsbruecke and the TMCL-IDE please make sure that JP3 on the evaluation board is set on positions 1-2. This should basically be the default factory setting. It configures the SPI channels mode. Setting 1-2 is required for the Landungsbruecke.




Figure 4: Top view of TMC8462A-EVAL

## 2 Evaluation Board Sections and Components

Figure 4 top view of the TMC8462A-EVAL shows the main connectors (green), signal pin headers (light blue), and jumper options (red).

The on-chip reset circuit takes care for proper power-on reset.

The tactile switch S1 in the upper right corner triggers a manual reset of the ESC and the PHYs.

### 2.1 Evaluation Board Connectors

Connector ID	Description
J1	Power supply connector for the evaluation board. Connect Ground and Supply here (5V-35V). Type: <a href="#">AKL320-02 by RIA</a>
J2	Left side 44-pin connector with control signals going to TRINAMIC's Landungsbruecke controller board or a users own controller board. The Eselsbruecke connector board fits onto this connector. Type: <a href="#">HLE-122-02-F-DV by Samtec</a>
J3	Right side 44-pin connector with configurable MFC IO signals of TMC8462A-BA. Type: <a href="#">HLE-122-02-F-DV by Samtec</a>
J9	Double RJ45 twisted pair copper (TPC) connector to connect the TMC8462A-EVAL to the EtherCAT bus. 10/100BaseT with integrated transformers. Type: <a href="#">7499021125 by Wuerth Elektronik</a>

Table 1: Board connectors

Please check the online available design files and schematic data for the connectors' signal connections and pinning.

### 2.2 Evaluation Board Pin Headers

There are 5 pin header groups on the TMC8462A-EVAL– J4 to J8.

Pin Header ID	Description
J4	General control signals
J5	MFC IO 16x low-voltage/digital IOs
J6	MFC IO 3x high-voltage IOs, pin group 1 using VIO1
J7	MFC IO 3x high-voltage IOs, pin group 2 using VIO2
J7	MFC IO 2x high-voltage IOs, pin group 3 using VIO3

Table 2: Pin header groups

J4 contains various control and debug signals.

The distributed clocks synchronization output trigger signals and input latch signals are available along with some PDI debug signals.

Using a 2-pin jumper bridge across pin 5 and pin 6 (RESET\_OUT to RST\_IN) enables using the internal reset signal of the ESC. Thereby, the EtherCAT master or the local host can issue a TMC8462A-BA device reset by writing a special character sequence into ESC registers 0x0040 or 0x0041.

Pin #	Description	Pin #	Description
1	SYNC_OUT0	2	LATCH_IN0
3	SYNC_OUT1	4	LATCH_IN1
5	RESET_OUT	6	RST_IN
7	+3.3V (= TMC8462A-BA SW0 output)	8	MFC_NES_EXT
9	PDI_SOF	10	GND
11	PDI_EOF	12	+3.3V (= TMC8462A-BA SW0 output)
13	CLK_16MHZ_OUT	14	+5V (from LDO U1)
15	GND	16	GND

*Table 3: Pin header J4 pinning – general control signals*

J5 allows access to all 16 low-voltage MFC IOs. They are using VCCIO = +3.3V. The actual function of these 16 MFC IOs is defined by the configuration of the MFC IO block's crossbar matrix and functional sub-blocks.

Pin #	Description	Pin #	Description
1	GND	2	+3.3V (= TMC8462A-BA SW0 output)
3	MFCIO08	4	MFCIO00
5	MFCIO09	6	MFCIO01
7	MFCIO10	8	MFCIO02
9	MFCIO11	10	MFCIO03
11	MFCIO12	12	MFCIO04
13	MFCIO13	14	MFCIO05
15	MFCIO14	16	MFCIO06
17	MFCIO15	18	MFCIO07
19	GND	20	+3.3V (= TMC8462A-BA SW0 output)

*Table 4: Pin header J5 pinning – MFC IO 16x low-voltage/digital IOs*

J6, J7, and J8 allow access to all 8 high-voltage MFC IOs. The voltage at these pins is configurable and can be up to the supply voltage. The 8 high-voltage MFC IOs are divided into three groups where each group has its own supply voltage. On the TMC8462A-EVAL VIO1 and VIO2 are the same and directly driven by VOUT . VIO2 can be selected using The actual function of these 8 MFC IOs is defined by the configuration of the MFC IO block's crossbar matrix and functional sub-blocks.

Pin #	Description
1	VOUT (= TMC8462A-BA SW1 output, configurable)
2	MFCHVIO00
3	MFCHVIO01
4	MFCHVIO02

Pin #	Description
5	GND

Table 5: Pin header J6 pinning – MFC IO 3x high-voltage IOs, pin group 1 using VIO1

Pin #	Description
1	VIO2 (= selectable and configurable)
2	MFCHVIO03
3	MFCHVIO04
4	MFCHVIO05
5	GND




Table 6: Pin header J7 pinning – MFC IO 3x high-voltage IOs, pin group 2 using VIO2

Pin #	Description
1	VOUT (= TMC8462A-BA SW1 output, configurable)
2	MFCHVIO06
3	MFCHVIO07
4	GND

Table 7: Pin header J8 pinning – MFC IO 2x high-voltage IOs, pin group 3 using VIO3

## 2.3 Evaluation Board Jumper Settings

Jumper ID	Default Connection Pins	Description
JP1	2-3	<p>JP1 selects the voltage used for bank 2 of the high voltage IOs VIO2. The default setting selects VOUT of the configurable buck regulator of TMC8462A-BA. The VOUT itself can further be selected with JP2. The second option of JP1 is to use a dedicated fixed 5V voltage regulator output.</p> <pre>     graph LR       JP1((JP1)) --- VOUT[VOUT]       JP1 --- +5V_REG[+5V_REG]       VOUT --- VIO2[VIO2]       +5V_REG --- VIO2   </pre>

Jumper ID	Default Connection Pins	Description
JP2	1-2	JP2 selects the configuration for the output voltage of the configurable internal buck regulator of TMC8462A-BA. The default setting ("fixed") uses a voltage divider configuration for $V_{OUT} = 5V$ . The second option ("VAR") allows directly controlling $V_{OUT}$ with the potentiometer R23. 
JP3	1-2	JP3 selects the configuration of the two SPI control interfaces of TMC8462A-BA (PDI SPI interface and MFC IO SPI interface). The default setting configures the interfaces to be two separate SPI buses with individual control and data signals. The second option is to physically share the PDI SPI bus and also allow access to the MFC IO SPI via the second chip select line. 
JP4	1-2	JP4 selects the EtherCAT operation mode of TMC8462A-BA. With the default setting, the EtherCAT slave controller operates in standard mode. TMC8462A-BA thereby expects a controller including an EtherCAT State Machine (ESM) implementation at the PDI interface. The second option is to start-up the ESC in so-called PDI- or device-emulation mode, which allows operation without an external controller. State changes are then directly executed in hardware in the ESC. 

Jumper ID	Default Connection Pins	Description
JP5	2-3	<p>JP5 selects the actual source of the low active (not) emergency switch input MFC_NES. MFC_NES has a weak internal pull down and must be driven high for normal operation. The default setting of JP5 configures the source of MFC_NES coming from pin header J4 at pin 8. The second option is that MFC_NES is driven by pin 23 of the 44-pin connector J2, for example by a connected TRINAMIC Landungsbruecke controller board.</p>

Table 8: Board jumper options and defaults

### 3 Evaluation Board Design Files

All design files for our evaluation boards are available for free. We offer the original ECAD files, Gerber data, the BOM, and PDF copies. Typically, the ECAD files are in KiCAD format. Some (older) evaluation boards may only be available in Eagle, Altium, or PADS format.

Please check schematics for Jumper settings and input/output connector description.

The files are available on the evaluation board website at <https://www.trinamic.com/support/eval-kits/>.

**Note** If files are missing on the website or something is wrong please send us a note.

## 4 Example XML File

The following example XML file is used as default configuration for the TMC8462A-EVAL. This XML file is available for download from the evaluation board's website. Besides the standard ESI/XML configuration it includes the following blocks:

- The MFC IO configuration vector, which is defined as category 1 data to be automatically loaded in the ESC Parameter RAM at 0x0580-0x05E1. It is all zero in this configuration.
  - DC mode configuration example
  - ESC configuration <ConfigData> with general/start-up PDI and interface configuration

```

29      <Timeout>
30          <PreopTimeout>2000</PreopTimeout>
31          <SafeopOpTimeout>9000</SafeopOpTimeout>
32          <BackToInitTimeout>5000</BackToInitTimeout>
33          <BackToSafeopTimeout>200</BackToSafeopTimeout>
34      </Timeout>
35  </StateMachine>
36  <Mailbox>
37      <Timeout>
38          <RequestTimeout>100</RequestTimeout>
39          <ResponseTimeout>2000</ResponseTimeout>
40      </Timeout>
41  </Mailbox>
42 </Info>
43 <GroupType>TrinamicEVAL</GroupType>

44 <Dc>
45     <OpMode>
46         <Name>Synchron</Name>
47         <Desc>FreeRun/SM-Synchron</Desc>
48         <AssignActivate>#x0</AssignActivate>
49     </OpMode>
50     <OpMode>
51         <Name>DC</Name>
52         <Desc>DC-Synchron</Desc>
53         <AssignActivate>#x300</AssignActivate>
54         <CycleTimeSync0 Factor="#1">0</CycleTimeSync0>
55         <ShiftTimeSync0>0</ShiftTimeSync0>
56         <CycleTimeSync1 Factor="#1">0</CycleTimeSync1>
57         <ShiftTimeSync1>0</ShiftTimeSync1>
58     </OpMode>
59 </Dc>

60 <Eeprom>
61     <ByteSize>2048</ByteSize>
62     <!-- General/Start-up ESC Configuration -->
63     <ConfigData>050E034EC40900000000</ConfigData>

64     <!-- MFC IO configuration vector -->
65     <!-- Category 1 data is required for the MFC IO configuration -->
66     <!-- This configuration is automatically written from EEPROM to -->
67     <!-- memory area 0x0580:0x05FF (ESC Parameter RAM). -->
68
69     <Category>
70         <CatNo>1</CatNo>
71         <Data>
72             0000000000000000000000000000000000000000000000000000000000000000
73             0000000000000000000000000000000000000000000000000000000000000000
74             0000000000000000000000000000000000000000000000000000000000000000
75             0000000000000000000000000000000000000000000000000000000000000000
76         </Data>
77     </Category>
78 </Eeprom>

79 <ImageData16x14>424dd60200000000000036000000280000010000000e0000000
80

```



## 5 Revision History

### 5.1 Document Revision

Version	Date	Author	Description
1.00	2018-02-26	SK	Initial release.
1.10	2018-06-15	SK	Update of getting started section.
1.20	2022-08-29	SK	Update from TMC8462 to TMC8462A version.

*Table 9: Document Revision*