



Installing a socket on mat

Installing a stud on mat

Tool includes two anvils, one for sockets, one for studs.

Description

The Desco model [09867](#) industrial grade Snap Attaching Tool is designed to install rivet style 10mm (3/8") snap sockets or studs onto mat materials. It is easy to use and only takes seconds. The tool is ideal for multiple snap installations. Due to its vise grip design it is not necessary to make a hole in the mat before installing snaps.

Installation

1. Install proper anvil on Snap Attaching Tool (see illustration).
2. Place rivet on rubber base of tool. Make sure it is secure.
3. Place stud or socket onto the anvil.
4. Squeeze handle tightly to install snap.
5. Adjust anvil travel to properly secure snap assembly: clockwise to tighten, and counter-clockwise to open jaws for thicker mats.

Specifications

Height: 12"
 Width: 5 3/8"
 Weight: 1.70 lb.

ITEM	DESCRIPTION
09867	Snap Attaching Tool
09856	Studs and Rivets, 100 per pack
09857	Sockets and Rivets, 100 per pack

Specifications and procedures subject to change without notice.

SNAP ATTACHING TOOL, 10MM (3/8")

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com
 PHONE (909) 627-8178 FAX (909) 627-7449 FAX REQUEST (909) 627-7126

DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407
 PHONE (781) 821-8370 FAX (781) 575-0172

**DRAWING
 NUMBER**
 09867

DATE:
 February
 2010

DESCO