

**+ CORPORATE HEADQUARTERS**

707 Dayton Road  
PO Box 1040  
Ottawa, IL 61350  
USA

p: (800) 346-3119  
f: (815) 433-5109

**+ EUROPEAN HEADQUARTERS**

Westlink Commercial Park  
Unit 10  
Oranmore, Co. Galway  
Ireland

p: + 353 91 792444  
f: + 353 91 792445

**+ CELLULAR PRODUCTS GROUP**

Sokolská 71  
562 04 Ústí nad Orlicí III.  
Czech Republic

p: +420 465 524 421

**Product EOL Notice**

October 10, 2019

Advantech B+B SmartWorx will no longer be selling the Wzzard Mesh Gen1 product line in favor of the Gen2 models.

| Model       | Description                                      | Replacement      |
|-------------|--|------------------|
| BB-WCD1TA3  | WLS ANALOG 3-AI SENSOR, INDOOR                   | BB-WCD1H2102H    |
| BB-WCD1TD2  | WLS 2DI, 2D SENSOR, INDOOR                       | BB-WCD1H2102H    |
| BB-WCD1TTJ  | WLS TEMP SENSOR, 2 THERMO JTYPE, INDOOR          | BB-WCD1H2102H    |
| BB-WCHOLST  | WALL MOUNT HOLSTER FOR INDOOR WCD WZZARD NODES   | None             |
| BB-WSD1CA2  | WLS ANALOG 2AI, 1DO SENSOR, INT ANT CONDUIT      | BB-WSD2C21150    |
| BB-WSD1CA3  | WLS ANALOG 3-AI SENSOR, INT ANT, CONDUIT         | BB-WSD2C31010    |
| BB-WSD1CD2  | WLS 2DI, 2DO SENSOR, INT ANT, CONDUIT            | BB-WSD2C06010    |
| BB-WSD1CTJ  | WLS TEMP SENS, 2 JTYPE, 1DO, CONDUIT, INT ANT    | BB-WSD2C21150    |
| BB-WSD1CTK  | WLS TEMP SENS, 2 KTYPE, 1DO, CONDUIT, INT ANT    | BB-WSD2C21150    |
| BB-WSD1MA2  | WLS ANALOG 2AI 1DO, INT ANT M12                  | BB-WSD2C21150    |
| BB-WSD1MA3  | WLS ANALOG 3-AI SENSOR, INT ANT, M12             | BB-WSD2M31010    |
| BB-WSD1MD2  | WLS DIGITAL 2DI, 2DO SENSOR, INT ANT, M12        | BB-WSD2M06010    |
| BB-WSD1XV0  | WLS ACCELEROMETER SENSOR, INT ANT                | BB-WSD2M3101P2K  |
| BB-WSD2CA2  | WLS ANALOG 2AI, 1DO SENSOR, EXT ANT CONDUIT      | BB-WSD2C21150    |
| BB-WSD2CA3  | Wzzard Wireless IO with 3DI, Ext. Antenna        | BB-WSD2C31010    |
| BB-WSD2CD2  | Wzzard Wireless IO with 2DI, 2DO, Ext. Antenna   | BB-WSD2C06010    |
| BB-WSD2CJA  | Wzzard Wireless IO with 2 I, 2TC, 1DO, Ext. Ant. | BB-WSD2C21150    |
| BB-WSD2CTJ  | WLS TEMP SENS, 2 JTYPE, 1DO, CONDUIT, EXT ANT    | BB-WSD2C21150    |
| BB-WSD2CTK  | WLS TEMP SENS, 2 KTYPE, 1DO, CONDUIT, EXT ANT    | BB-WSD2C21150    |
| BB-WSD2MA2  | WLS ANALOG 2AI, 1DO SENSOR, EXT ANT M12          | BB-WSD2C21150    |
| BB-WSD2MA3  | WLS ANALOG 3-AI SENSOR, EXT ANT, M12             | BB-WSD2M31010    |
| BB-WSD2MD2  | WLS DIGITAL 2DI, 2DO SENSOR, EXT ANT, M12        | BB-WSD2M06010    |
| BB-WSD2XV0  | Wzzard Wireless IO with Motion Sensor, Ext. Ant. | BB-WSD2M3101P2K  |
| BB-ERT351   | ETH DUST SL set USA                              | BB-SG30000525-42 |
| BB-RT3G-350 | 3G DUST SL Set USA                               | BB-SG30500520-42 |
| BB-RT3G-351 | 3G ETH DUST SL Set USA                           | BB-SG30500520-42 |
| BB-RT3G-352 | 3G RS232 DUST SL Set USA                         | BB-SG30500520-42 |
| BB-RT3G-354 | 3G RS485 DUST SL Set USA                         | BB-SG30500520-42 |

**+ CORPORATE HEADQUARTERS**

707 Dayton Road  
PO Box 1040  
Ottawa, IL 61350  
USA

p: (800) 346-3119  
f: (815) 433-5109

**+ EUROPEAN HEADQUARTERS**

Westlink Commercial Park  
Unit 10  
Oranmore, Co. Galway  
Ireland

p: + 353 91 792444  
f: + 353 91 792445

**+ CELLULAR PRODUCTS GROUP**

Sokolská 71  
562 04 Ústí nad Orlicí III.  
Czech Republic

p: +420 465 524 421

| Model             | Description                                      | Replacement  |
|-------------------|--|--------------|
| BB-WSKIT3BC-CBM   | WZZARD CONDITION BASED MONITORING KIT, CELL GW   | BB-WSK-CBM-2 |
| BB-WSKIT3BC-CBM-V | WZD CONDITION MONITORING KT, CELL GW, VIB SENSOR | BB-WSK-CBM-2 |
| BB-WSKIT3BC-NRG   | WZZARD ENERGY MONITORING KIT, 3 NODE, CELL GW    | BB-WSK-NRG-2 |
| BB-WSKIT3BE-CBM   | WZZARD CONDITION MONITOR KIT, 3 NODE, ETN GW     | BB-WSK-CBM-2 |
| BB-WSKIT3BE-CBM-V | WZZARD CONDITION MONITOR KIT+VIB, 3 NODE, ETN GW | BB-WSK-CBM-2 |
| BB-WSKIT3BE-NRG   | WZZARD ENERGY MONITOR KIT, 3 NODE, ETN GW        | BB-WSK-NRG-2 |
| BB-WSKIT4BC       | Wzzard Dev kit, cell GW, 4 sensor nodes          | None         |
| BB-WSKIT4BE       | Wzzard Dev kit, ETN GW, 4 sensor nodes           | None         |
| BB-WSK-HAC-1      | WZZARD HVAC MONITORING STARTER KIT               | BB-WSK-HAC-2 |
| BB-WSK-NRG-1      | WZZARD STARTER KIT - ENERGY MONITORING           | BB-WSK-NRG-2 |

Thank You,



Kevin Nelson, Product Manager