

AMP 1281-1 (6/65) 65 APPLICATOR PARTS LIST				TYPE MINIATURE QUICK CHANGE APPLICATOR END FEED			AMP INCORPORATED HARRISBURG, PENNA.			TYPE CODE <input type="checkbox"/> PROD <input type="checkbox"/> IN DIR <input type="checkbox"/> W.C.	
NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS
1	WIRE CRIMPER 453895-1	1	690627-1	43	WASHER-LAMINATED	1	690125-1	TO APPLY TERMINAL			60741
2	SPACER - INSULATION			44	RAM	1	690625-1	AMP EDGE (LEFT HAND)			60787
3	INSULATION CRIMPER			45	PLUG-NYLON	1	690191-1	PAD LETTER	CRIMP HEIGHT	WIRE SIZE	61782-2
4	PIN - CRIMPER			46	BLOCK-INS. ADJ.			A	.056060	1 #16	
5	SHEAR BLADE SPACER	1	4-240641-3	47	SCREW-SHOULDER			B	.049052	1 #18	
6	HOLD DOWN			48	CAM	1	690602-2	C	.041047	1 #20	
7	SHEAR BLADE	1	690627-1	49	CRIMPER BOLT	1	7-21002-9	D	.042044	1 #22	
8	ANVIL	1	240654-9	50				CRIMP	SIZE	TYPE	FEED
9	FRONT SHEAR PLATE 1-240642-2	1	240642-2	51				WIRE	.080	F	
10	SHEAR PLATE SPACER	2	1-240645-4	52	LEVER-TERMINAL	1	240634-1	INSUL.			.430
11	REAR SHEAR PLATE	1	240644-1	53	FEED FINGER	1	690626-1	INSULATION RANGE		WIRE RANGE	
12	HOLD DOWN SPRING			54	FEED FINGER SPRING	1	240638-1			22 - 16	
13	SPRING SPACER			55	FEED FINGER PIN	1	240624-1	EXPLODED VIEW		SET UP GAGE	
14	HOLD DOWN SPACER			56				A-6032-1,-2		679108-1	
15				57				REMARKS:			
16	SPRING - FEED RETURN	1	3-22287-0	58	HOUSING	1	240619-1	Pre Feed			
17	ANCHOR - SPRING	1	238008-1	59	CAP	1	240621-1	Amp-O-lectric			
18	FRONT - STRIP GUIDE 454204-1	1	240645-1	60	WEAR PLATE	1	240845-1				
19	REAR - STRIP GUIDE	1	693656-2	61	ROD-FEED	1	240631-1				
20	DRAG - STOCK	1	690628-1	62	ROLLER-CAM	1	240658-1				
21	DRAG LEVER	1	240636-1	63	PIN-CAM ROLLER	1	240659-1				
22	DRAG SPRING	1	7-22282-5	64	SCREW-ADJ.	1	240632-1				
23	PLATE - STRIP HOLD	1	693658-1	65	BLOCK-PIVOT	1	240629-1				
24	STRIP GUIDE PLATE	1	693658-1	66	LEVER-INTERMEDIATE	1	240630-1				
25	BASE BLOCK	1	240647-1	67	BUSHING	1	240633-1				
26	BASE PLATE	1	240652-1	68	SHAFT-PIVOT	1	240626-1				
27	STRIPPER	1	240639-1	69	PLATE ADJ.	1	240628-1				
28	RETAINING PLATE			70	HEX NUT	1	22594-8				
29	SHOULDER SCREW			71	SPACER	1	690517-1				
30	ANCHOR SPACER	1	690453-1	72	Spring Assist	1	690603-1				
31	SPACER - BASE BLOCK			73							
32	Spacer-Stripper	1	1-690451-4	74							
33				75							
34				76							
35	POST-RAM	1	690212-1	77							
36	SPRING WASHER 22480-5	1	690133-1	78	GUARD (WINDOW)	REF	455745-1				
37	DISC-WIRE	1	3-690111-2	79	Guard		690635-1				
38	DISC-INSULATION			REV.	REVISION RECORD	DATE	BY	ECN			
39	SPRING-COMPRESSION	1	690170-1	A	REV. PER ECN	7-16-70	WJ	L-1672			
40	BALL STEEL	1	23241-6	B	REV PER ECN	1-4-71	WJ	L-8208			
41	DISC SPACER	1	690223-1	BI	REV PER ECN	3-8-71	WJ	L-8149			
42	WASHER RAM	1	690124-1	C	REV PER ECN	11-22-71	WJ	L-8604			
				D	REV PER ECN	4-21-72	RS	L-8854			
				E	REV PER ECN	2-9-77	WJ	L-1974			
51 ADDEND 61782-2 R21201mg7/71								THIS APPLICATOR IS TO BE USED ON			
MACH. SERIAL NO.								DIST.			
MACH. PARTS LIST 565435-5								DESIGNED			
APPL. SERIAL NO.								DATE SHIPPED			
CUSTOMER NAME AND ADDRESS								CHK'D.			
APPLICATOR NUMBER								SHEET			
REV. 686279-2								1 OF 1			

For Hardware See 687011-2