

July 10, 2017

Product Information (PI1652) Production Change Notice **Discontinuation of Series 44** Series 44

Contact

EAO Corporation
One Parrott Drive
Shelton, CT 06484
Phone +1 203 951 4600
Fax +1 203 951 4601

Discontinuation of Series 44.

Due to expanding market demands, a major portion of EAO Series 44, 22.5mm product line will be officially discontinued at the end of 2017.

With the introduction of the new, modern and comparable Series 45, this represents the next step in the product life cycle of the Series 44, which has been in service for many years. Alternative products with similar sizes can be found in EAO Series 45, 04 and 14.

The portion of the series to be discontinued includes:

- Pushbuttons
- Emergency Stop/Stop Switches
- Selectors
- Keylocks
- Indicators

The portion of the series that will remain available:

- 2,4,& 8 Position Joysticks
- Potentiometers

The affected part numbers include and extend beyond what is listed in our current price lists.

Please refer to the list below of the affected part numbers, both discontinued and part numbers that will remain available.

- The last date we can accept orders for the discontinued items is November 15, 2017.
- Scheduled release dates for these orders are permitted up to December 31, 2017.
- After December 31, 2017, availability of the discontinued items will be limited to only “in-house” existing stock until their depletion.

DISCONTINUED ITEMS

| Part no. | Description |
|---------------|---|
| 44-111 | Switching Element front mounting 1NC |
| 44-112 | Switching Element front mounting gold/silver 1NC |
| 44-121 | Switching Element front mounting 1NO |
| 44-131 | Switching Element front mounting 1NC+1NO |
| 44-132 | Switching Element front mounting gold/silver 1NC+1NO |
| 44-141 | Switching Element front mounting overlapping 1NC+1NO |
| 44-151 | Switching Element front mounting 1NC |
| 44-152 | Switching Element front mounting gold/silver 1NC |
| 44-161 | Switching Element front mounting 1NO |
| 44-162 | Switching Element front mounting gold/silver 1NO |
| 44-211 | Switching Element base mounting 1NC |
| 44-221 | Switching Element base mounting 1NO |
| 44-524 | Lamp element for front mounting |
| 44-525 | Lamp element for base mounting |
| 44-701.20 | Pushbutton-actuator black matt chrome mom |
| 44-701.20.100 | Pushbutton mom black matt chrome 1NC+1NO |
| 44-701.22 | Pushbutton-actuator red matt chrome mom |
| 44-701.22.001 | Pushbutton mom red matt chrome 1NC |
| 44-701.22B | Pushbutton-actuator red mom without front ring |
| 44-701.24 | Pushbutton-actuator yellow matt chrome mom |
| 44-701.24.010 | Pushbutton mom yellow matt chrome 1NO |
| 44-701.25 | Pushbutton-actuator green matt chrome mom |
| 44-701.25.010 | Pushbutton mom green matt chrome 1NO |
| 44-701.25B | Pushbutton-actuator green mom without front ring |
| 44-701.26 | Pushbutton-actuator mom blue matt chrome |
| 44-701.27 | Pushbutton-actuator mom clear matt chrome |
| 44-701.29 | Pushbutton-actuator white matt chrome mom |
| 44-701.60 | Pushbutton-actuator black mom |
| 44-701.62 | Pushbutton-actuator red mom |
| 44-701.64 | Pushbutton-actuator yellow mom |
| 44-701.65 | Pushbutton-actuator green mom |
| 44-701.66 | Pushbutton-actuator mom blue |
| 44-701.69 | Pushbutton-actuator white mom |
| 44-702.20 | Pushbutton-actuator black matt chrome main |
| 44-702.20.100 | Pushbutton main black 1NC+1NO |
| 44-702.22 | Pushbutton-actuator red matt chrome main |
| 44-702.24 | Pushbutton-actuator yellow matt chrome main |
| 44-702.25 | Pushbutton-actuator green matt chrome main |
| 44-702.25.010 | Pushbutton main green 1NO |
| 44-702.26 | Pushbutton-actuator blue matt chrome main |
| 44-702.60 | Pushbutton-actuator black main |
| 44-702.62 | Pushbutton-actuator red main |
| 44-702.65 | Pushbutton-actuator green main |
| 44-703.20 | Pushbutton-actuator mom, with front ring black matt chrome |
| 44-703.22 | Pushbutton-actuator mom, with front ring red matt chrome |
| 44-703.24 | Pushbutton-actuator mom, with front ring yellow matt chrome |
| 44-703.25 | Pushbutton-actuator mom, with front ring green matt chrome |
| 44-703.26 | Pushbutton-actuator mom, with front ring blue matt chrome |
| 44-703.62 | Pushbutton-actuator mom, with front ring red raised |
| 44-704.22 | Pushbutton-actuator mom, with raised knob red matt chrome |
| 44-704.22B | Pushbutton-actuator mom, with raised knob red without ring |
| 44-704.65 | Pushbutton-actuator mom, with raised knob green |
| 44-707.20 | Mushroom-head pushbutton black matt chrome |
| 44-707.22 | Mushroom-head pushbutton red matt chrome |
| 44-707.25 | Mushroom-head pushbutton green matt chrome |
| 44-707.64 | Mushroom-head pushbutton yellow |
| 44-709.27 | Push Rod actuator colorless with threading M4 |
| 44-710 | Switch emergency-stop-actuator red D50 |
| 44-710.001 | Switch emergency-stop red D50 1NC |
| 44-711 | Switch emergency-stop-actuator red D37 |
| 44-711-C | Switch emergency-stop-actuator special |
| 44-712 | Switch emergency-stop-actuator with twist release foolproof |
| 44-712.001 | Switch emergency-stop with twist release foolproof D37 1NC |
| 44-713 | Switch emergency-stop with key release foolproof red D37 |
| 44-720.20 | Selector switch-actuator 2 positions black matt chrome main |
| 44-720.20.100 | Selector switch 2 positions black matt 1NC+1NO main |
| 44-720.22 | Selector switch-actuator 2 positions red matt chrome main |
| 44-720.62 | Selector switch-actuator 2 positions red main |
| 44-720.68 | Selector switch-actuator 2 positions grey main |
| 44-722.20 | Selector switch-actuator 2 positions black matt chrome mom |
| 44-722.68 | Selector switch-actuator 2 positions grey mom |
| 44-724.20 | Selector switch-actuator 3 positions black main-0-main |

| Part no. | Description |
|---------------|---|
| 44-750.65 | Indicator shape 1 green |
| 44-750.66 | Indicator shape 1 blue |
| 44-750.67 | Indicator shape 1 colorless |
| 44-751.22 | Indicator shape 2 red matt chrome |
| 44-751.22.000 | Indicator shape 2 red |
| 44-751.24 | Indicator shape 2 yellow matt chrome |
| 44-751.24.000 | Indicator shape 2 yellow |
| 44-751.25 | Indicator shape 2 green matt chrome |
| 44-751.25.000 | Indicator shape 2 green |
| 44-751.26 | Indicator shape 2 blue matt chrome |
| 44-751.29 | Indicator shape 2 white matt chrome |
| 44-751.29.000 | Indicator shape 2 white |
| 44-751.62 | Indicator shape 2 red |
| 44-751.64 | Indicator shape 2 yellow |
| 44-751.65 | Indicator shape 2 green |
| 44-751.66 | Indicator shape 2 blue |
| 44-751.69 | Indicator shape 2 white |
| 44-770.2 | Double pushbutton chrome |
| 44-771.2 | Double pushbutton marking chrome |
| 44-772.2 | Double pushbutton chrome color of operation part: 2x green |
| 44-773.2 | Double pushbutton chrome color of operation part: black / white |
| 44-774.2 | Double pushbutton chrome color of operation part: black / white |
| 44-800.A | Lever switch |
| 44-900 | Front adaptor 0 |
| 44-901 | Front adaptor 1 |
| 44-902 | Front adaptor 2 |
| 44-903 | Front adaptor 3 |
| 44-905 | Base adaptor |
| 44-915 | Blanking plate 2 |
| 44-919 | Spare key lock 9500 |
| 44-919.A | Spare key brass |
| 44-921.00 | Lock cap black |
| 44-921.08 | Lock cap grey |
| 44-925 | Reducing ring |
| 44-926.8 | Fixing nut black |
| 44-935 | Mounting tool |
| 44-940 | Blank element |
| 44-944.00 | Label support black |
| 44-944.08 | Label support grey |
| 44-945.00 | Label support black with unmarked label |
| 44-945.08 | Label support grey with unmarked label |
| 44-946 | Label silver 27x18 |
| 44-946.0 | Label black 27x18 |
| 44-946.01 | Front bezel-set, flush mounting without label support |
| 44-946.01-A | Front bezel-set, flush mounting round |
| 44-946.02 | Front bezel-set, flush mounting with label support |
| 44-946.03 | Front bezel-set, flush mounting flat without label support |
| 44-946.03-A | Front bezel-set, flush mounting flat round |
| 44-946.04 | Front bezel-set, flush mounting flat with label support |
| 44-955 | Legend plate |
| 44-960 | Label 13x26 |
| 44-960-T03 | Label 13x26 engraved |
| 44-960-T27 | Label 13x26 engraved |
| 44-962.9 | Marking plate white for illuminated pushbutton |
| 44-964.3 | Scale |
| 44-964.3A | Scale dial alu with semicircular tail |
| 44-965.2 | Lens shape 1 cap red |
| 44-965.4 | Lens shape 1 cap yellow |
| 44-965.5 | Lens shape 1 cap green |
| 44-965.6 | Lens shape 1 cap blue |
| 44-965.7 | Lens shape 1 cap colorless |
| 44-966.2 | Lens red for indicator shape 2 and illuminated pushbutton actuator |
| 44-966.4 | Lens yellow for indicator shape 2 and illuminated pushbutton |
| 44-966.5 | Lens green for indicator shape 2 and illuminated pushbutton |
| 44-966.6 | Lens blue for indicator shape 2 and illuminated pushbutton actuator |
| 44-966.7 | Lens colorless for indicator shape 2 and illuminated pushbutton |
| 44-967.2 | Front ring matt chrome |
| 44-967.6 | Front ring |
| 44-969.0 | Lens black for pushbutton |
| 44-969.2 | Lens red for pushbutton |
| 44-976 | Lamp transformer 220V/24V |
| 44-977 | Lamp transformer 380V/24V |

| | |
|---------------|--|
| 44-724.20.020 | Selector switch 3 positions black matt main-0-main 2NO |
| 44-724.60 | Selector switch-actuator 3 positions black main-0-main, |
| 44-724.68 | Selector switch-actuator 3 positions grey main-0-main |
| 44-725.20 | Selector switch-actuator 3 positions black matt mom-0-mom |
| 44-725.68 | Selector switch-actuator 3 positions grey mom-0-mom |
| 44-726.20 | Selector switch-actuator 3 positions black matt main-0-mom |
| 44-726.68 | Selector switch-actuator 3 positions grey main-0-mom |
| 44-727.20 | Selector switch-actuator 3 positions black matt mom-0-main |
| 44-730.21 | Keylock switch-actuator 2 positions matt chrome main |
| 44-730.21-A | Schlüsselschalter-Vorsatz 2-St. |
| 44-730.21.100 | Keylock switch 2 positions mat chrome main 1NC+1NO |
| 44-730.22 | Keylock switch-actuator 2 positions matt chrome main |
| 44-730.22.100 | Keylock switch 2 positions mat chrome main 1NC+1NO |
| 44-730.61 | Keylock switch-actuator 2 positions main |
| 44-730.62 | Keylock switch-actuator 2 positions main |
| 44-732.21 | Keylock switch-actuator 2 positions matt chrome mom |
| 44-732.61 | Keylock switch actuator 2 positions mom |
| 44-740.00 | Rotating knob 18/6 black/black |
| 44-742.20 | Interlocking button black matt chrome |
| 44-742.22 | Interlocking button red matt chrome |
| 44-746.22 | Illuminated pushbutton-actuator red matt chrome mom |
| 44-746.22.001 | Illuminated pushbutton red mom 1NC |
| 44-746.24 | Illuminated pushbutton-actuator yellow matt chrome mom |
| 44-746.24.010 | Illuminated pushbutton yellow mom 1NO |
| 44-746.25 | Illuminated pushbutton-actuator green matt chrome mom |
| 44-746.25-A | Illuminated pushbutton-actuator green matt chrome mom |
| 44-746.25.010 | Illuminated pushbutton green mom 1NO |
| 44-746.26 | Illuminated pushbutton-actuator blue matt chrome mom |
| 44-746.29 | Illuminated pushbutton-actuator white matt chrome mom |
| 44-746.29.100 | Illuminated pushbutton white mom 1NC+1NO |
| 44-746.62 | Illuminated pushbutton-actuator red mom |
| 44-746.64 | Illuminated pushbutton-actuator yellow mom |
| 44-746.65 | Illuminated pushbutton-actuator green mom |
| 44-746.66 | Illuminated pushbutton-actuator blue mom |
| 44-746.69 | Illuminated pushbutton-actuator white mom |
| 44-747.22 | Illuminated pushbutton-actuator red matt chrome main |
| 44-747.24 | Illuminated pushbutton-actuator yellow matt chrome main |
| 44-747.24.010 | Illuminated pushbutton green main 1NO |
| 44-747.25 | Illuminated pushbutton-actuator green matt chrome main |
| 44-747.25.010 | Illuminated pushbutton green main 1NO |
| 44-747.26 | Illuminated pushbutton-actuator blue matt chrome main |
| 44-747.29 | Illuminated pushbutton-actuator white matt chrome main |
| 44-747.29.100 | Illuminated pushbutton white main 1NC+1NO |
| 44-747.62 | Illuminated pushbutton-actuator red main |
| 44-747.64 | Illuminated pushbutton-actuator yellow main |
| 44-747.65 | Illuminated pushbutton-actuator green main |
| 44-747.66 | Illuminated pushbutton-actuator blue main |
| 44-747.69 | Illuminated pushbutton-actuator white main |
| 44-750.22 | Indicator shape 1 red matt chrome |
| 44-750.22.000 | Indicator shape 1 red |
| 44-750.24 | Indicator shape 1 yellow matt chrome |
| 44-750.24.000 | Indicator shape 1 yellow |
| 44-750.25 | Indicator shape 1 green matt chrome |
| 44-750.25.000 | Indicator shape 1 green |
| 44-750.26 | Indicator shape 1 blue matt chrome |
| 44-750.27 | Indicator shape 1 colorless matt chrome |
| 44-750.27.000 | Indicator shape 1 colorless |
| 44-750.62 | Indicator shape 1 red |
| 44-750.64 | Indicator shape 1 yellow |

| | |
|-------------------|---|
| 44-XXX | Switches and accessories Series 44 |
| 44.131.00 | Switching Element 1NC+1NO |
| 44.701.200 | Pushbutton-actuator black matt chrome mom with accessories |
| 44.701.202 | Pushbutton-actuator red matt chrome mom with accessories |
| 44.701.204 | Pushbutton-actuator yellow matt chrome mom with accessories |
| 44.701.205 | Pushbutton-actuator green matt chrome mom with accessories |
| 44.701.206 | Pushbutton-actuator mom blue matt chrome with accessories |
| 44.701.209 | Pushbutton-actuator white matt chrome mom with accessories |
| 44.702.200 | Pushbutton-actuator black matt chrome main with accessories |
| 44.702.202 | Pushbutton-actuator red matt chrome main with accessories |
| 44.704.204 | Pushbutton-actuator mom, with raised knob yellow matt chrome |
| 44.707.202 | Mushroom-head pushbutton red matt chrome with accessories |
| 44.707.204 | Mushroom-head pushbutton yellow matt chrome with accessories |
| 44.707.205 | Mushroom-head pushbutton green matt chrome with accessories |
| 44.710.00 | Switch emergency-stop-actuator red D50 with accessories |
| 44.711.00 | Switch emergency-stop-actuator red D37 with accessories |
| 44.712.00 | Switch emergency-stop-actuator with twist release foolproof red |
| 44.713.00 | Switch emergency-stop with key release foolproof red D37 |
| 44.720.200 | Selector switch-actuator 2 positions black matt chrome main |
| 44.722.200 | Selector switch-actuator 2 positions matt chrome mom |
| 44.724.200 | Selector switch-actuator 3 positions black matt main-0-main |
| 44.730.201 | Keylock switch-actuator 2 positions matt chrome main |
| 44.730.202 | Keylock switch-actuator 2 positions matt chrome main |
| 44.732.201 | Keylock switch-actuator 2 positions matt chrome mom |
| 44.734.201 | Keylock switch-actuator 3 positions matt chrome main-0-main |
| 44.734.204 | Keylock switch-actuator 3 positions matt chrome main-0-main |
| 44.734.205 | Keylock switch-actuator 3 positions matt chrome main-0-main |
| 44.737.201 | Keylock switch-actuator 3 positions matt chrome mom-0-main |
| 44.746.202 | Illuminated pushbutton-actuator red matt chrome mom |
| 44.746.204 | Illuminated pushbutton-actuator yellow matt chrome mom |
| 44.746.205 | Illuminated pushbutton-actuator green matt chrome mom |
| 44.746.206 | Illuminated pushbutton-actuator blue matt chrome mom |
| 44.746.209 | Illuminated pushbutton-actuator white matt chrome mom |
| 44.747.205 | Illuminated pushbutton-actuator green matt chrome main |
| 44.750.200 | Indicator shape 1 without lens cap matt chrome |
| 44.750.202 | Indicator shape 1 red matt chrome |
| 44.750.204 | Indicator shape 1 yellow matt chrome |
| 44.750.205 | Indicator shape 1 green matt chrome |
| 44.750.206 | Indicator shape 1 blue matt chrome |
| 44.750.207 | Indicator shape 1 clear matt chrome |
| 44.751.202 | Indicator shape 2 red matt chrome |
| 44.751.209 | Indicator shape 2 white matt chrome |
| 44.950.02 | Legend plate for Emergency-Stop switch D60 |
| EUS-44-01273 | Pushbutton Assembly |
| EUS-44-05552 | Pushbutton Assembly |
| EUS-44-05652 | Pushbutton Assembly |
| EUS-44-06552 | Pushbutton Assembly |
| EUS-44-06559 | Pushbutton Assembly |
| EUS-44-06562 | Pushbutton Assembly |
| EUS-44-24551 | Pushbutton Assembly |
| EUS-44-30554 | Pushbutton Assembly |
| EUS-44-30555 | Pushbutton Assembly |
| EUS-44-33550 | Pushbutton Assembly |
| EUS-44-33560 | Pushbutton Assembly |
| EUS-44-34551 | Pushbutton Assembly |
| EUS-44-701.26/005 | Pushbutton Assembly |
| EUS-44-701.29/033 | Pushbutton Assembly |
| EUS-44-771.2/003 | Pushbutton Assembly |
| EUS-44-92502 | Pushbutton Assembly |

ITEMS NOT DISCONTINUED

| Part no. | Description |
|----------------|--|
| 44-744.20 | Potentiometer-drive without Potentiometer matt chrome |
| 44-744.60 | Potentiometer-drive without Potentiometer |
| 44-744.A | Potentiometer-drive Series 04 flush mounted without Pot. |
| 44-744.C | Potentiometer-drive Series 04 flush mounted black without Pot. |
| 44-744.D | Potentiometer-drive without Potentiometer |
| 44-744.E | Potentiometer-drive without Potentiometer special |
| 44-744.F | Potentiometer-drive Series 04 flush mounted without Pot. |
| 44-744.G | Potentiometer-drive Series 04 flush mounted without Pot. |
| 44-744.M | Potentiometer-drive Series 04 flush mounted natural without Pot. |
| 44-744.N | Potentiometer-drive Series 04 flush mounted black without Pot. |
| 44-745.20-10K1 | Potentiometer-drive 10 kOhm lin. matt chrome |
| 44-745.20-1K1 | Potentiometer-drive 1 kOhm lin. matt chrome |
| 44-745.20-1M1 | Potentiometer-drive 1 MOhm lin. matt chrome |
| 44-745.20-2K1 | Potentiometer-drive 2,2 kOhm lin. matt chrome |
| 44-745.20-33.1 | Potentiometer-drive 33 Ohm |
| 44-745.20-47K1 | Potentiometer-drive 47 kOhm lin. matt chrome |
| 44-745.20-4K1 | Potentiometer-drive 4,7 kOhm lin. matt chrome |

| Part no. | Description |
|----------------|--|
| 44-745.60-10K1 | Potentiometer-drive 10 kOhm lin. |
| 44-745.60-22K1 | Potentiometer-drive 22 kOhm lin. |
| 44-745.60-47K1 | Potentiometer-drive 47 kOhm lin. |
| 44-745.60-4K1 | Potentiometer-drive 4,7 kOhm lin. |
| 44-745.D | Potentiometer-drive Series 04 flush mounted Front ring hell 10kOhm lin |
| 44-745.E | Potentiometer-drive Series 04 flush mounted 10kOhm lin. |
| 44-745.G | Potentiometer-drive Series 04 flush mounted 50 Ohm lin. |
| 44-745.P | Potentiometer-drive flush mounted 1 kOhm, special |
| 44-745.P-3 | Potentiometer-drive flush mounting, 1 k, (Vishay P30LL0FRR102MA) |
| 44-745.S | Potentiometer actuator flush mount, 2.2kOhm pot. (SPECIAL) |
| 44-745.T | Potentiometer-drive Series 04 flush mounted 10kOhm lin. with switch |
| 44-745.U | Potentiometer actuator flush mount, 47kOhm pot. (SPECIAL) |
| 44-745.V | Potentiometer-drive special flush mounting |
| 44-800.2 | Control switch 2 positions main 63mm |
| 44-800.4 | Control switch 4 positions main 63mm |
| 44-800.8 | Control switch 8 positions main 63mm |
| 44-801.4 | Control switch 4 positions main 30mm |

Please note: EAO Series 45 offers many of the same features with expanded specifications and is considered the most viable alternative to the Series 44. Please contact EAO Customer Service to assist with cross referencing.