

Light is OSRAM

18.04.2016

OS-PD-2016-010

Last order: Stop immediately

Last delivery: Stop immediately

Reason: Portfolio streamline

Please note that this PDN affects Q-codes for special grouping and packing that are no longer requested by customers; the same products in standard grouping and packing are not affected and can be offered as replacement.

Please direct your inquiry to your local Sales office.

DISCONTINUED				NEW (REPLACEMENT)			
Device	Ordering Code	Function	Brand	Device	Ordering Code	Function	Brand
DURIS P 5							
GR DASPA1.23-FSFU-45-FJ-100-R18-CK	Q65111A6100	SSL	DURIS	Use STANDARD Q#			
GT DASPA1.13-GRGT-45-MP-100-R18-CK	Q65111A6099	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-HPHR-5H7I-1-100-R18-XX	Q65111A3094	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-GUHQ-5R8T-1-100-R18-XX	Q65111A3095	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-GUHR-5R8T-KN-100-R18-SA-CK	Q65111A6116	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-HPHR-5L7N-KN-100-R18-SA-CK	Q65111A6117	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-GUHR-5O8Q-KN-100-R18-SA-CK	Q65111A6118	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.EC-GUHQ-5U8X-KN-100-R18-SA-CK	Q65111A6150	SSL	DURIS	Use STANDARD Q#			
GW DASPA1.UC-HPHR-5F8G-1-100-R18	Q65111A5934	SSL	DURIS	Use STANDARD Q#			
GY DASPA1.23-FQFS-45-FJ-100-R18-CK	Q65111A6106	SSL	DURIS	Use STANDARD Q#			

DISCONTINUED				NEW (REPLACEMENT)			
Device	Ordering Code	Function	Brand	Device	Ordering Code	Function	Brand
DURIS E 5							
GW JDSMS1.CC-FQFS-5O8Q-L1N2-120-R18	Q65111A6482	SSL	DURIS	Use STANDARD Q#			
GW JDSMS1.EC-FSFU-6M7N-L1N1-120-R18	Q65111A6345	SSL	DURIS	Use STANDARD Q#			
GW JDSMS1.EC-FSFU-6S6T-L1N2-120-R18-XX	Q65111A6715	SSL	DURIS	Use STANDARD Q#			
GW JDSMS1.EC-FSFT-6M7N-L1N2-120-R18-XX	Q65111A6841	SSL	DURIS	Use STANDARD Q#			
GW JDSMS1.EC-FRFS-6U7W-L1N2-120-R18-XX	Q65111A6842	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FUGQ-5O8Q-L1N2-120-R18-SM	Q65111A6889	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FUGQ-5L7N-L1N2-120-R18-SM	Q65111A6890	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FUGQ-5H7I-L1N2-120-R18-SM	Q65111A6891	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FUGQ-5E8G-L1N2-120-R18-SM	Q65111A6892	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FUGQ-5C8E-L1N2-120-R18-SM	Q65111A6893	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-5R8T-L1N2-120-R18-SM	Q65111A6894	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FSGP-5U8X-L1N2-120-R18-SM	Q65111A6895	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-5O8Q-L1N2-120-R33	Q65111A7052	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-5L7N-L1N2-120-R33	Q65111A7053	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-6R6S-L1M1-120-R18-SA	Q65111A7074	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-6O6P-L1M1-120-R33-SB	Q65111A7076	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-6M6N-L1M1-120-R33-SC	Q65111A7077	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FTGP-6M-1-120-R18-XX	Q65111A7270	SSL	DURIS	Use STANDARD Q#			
GW JDSRS1.EC-FSFU-6V7V-1-120-R18-XX	Q65111A7271	SSL	DURIS	Use STANDARD Q#			
LCW JDSI.EC-FSFU-6M7N-L1N2-120-R18-XX	Q65111A3968	SSL	DURIS	Use STANDARD Q#			
DURIS E 3							
LCW JNSH.EC-BRBT-6R7T-L1N2-20-R18-Z	Q65111A3092	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BSBT-6R7S-L1M2-20-R18-ZC	Q65111A3298	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BSBU-5M6N-1-20-R18	Q65111A3355	SSL	DURIS	Use STANDARD Q#			

DISCONTINUED				NEW (REPLACEMENT)			
Device	Ordering Code	Function	Brand	Device	Ordering Code	Function	Brand
LCW JNSH.EC-BRBT-6S7U-L1N2-20-R18-SA-XX	Q65111A3650	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BSBU-6L6N-L1N2-20-R18-XX	Q65111A3659	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BRBT-5R7S-1-20-R18-XX	Q65111A4816	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BTBU-6R7S-L1N2-20-R18-XX	Q65111A4967	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BTBU-5H6I-L1N2-20-R18-XX	Q65111A5052	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BTBU-6R7S-L1M2-20-R18-XX	Q65111A5496	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BTCP-6R6S-L2M2-20-R18-XX	Q65111A6534	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BTCP-5H7I-L1M2-20-R18-SB-XX	Q65111A6977	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.EC-BRBT-6U6X-1-20-R18-XX	Q65111A7285	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.PC-BUCQ-5L8N-1-20-R18	Q65111A5854	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.PC-BUCQ-5H8I-1-20-R18	Q65111A5855	SSL	DURIS	Use STANDARD Q#			
LCW JNSH.PC-BUCQ-6H7I-1-20-R18-XX	Q65111A6184	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.EC-BSBU-5C8E-L1M2-20-R18	Q65111A3025	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.EC-BTCP-5E8G-1-20-R18-XX	Q65111A4139	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.EC-BTCP-6E7G-L1N2-120-R18-XX	Q65111A4742	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.EC-BTCP-5C7E-L1M1-20-R18-XX	Q65111A6405	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.PC-BTCQ-6C7E-L1N2-20-R18-XX	Q65111A4732	SSL	DURIS	Use STANDARD Q#			
LUW JNSH.PC-BUCQ-5C8D-1-20-R18-XX	Q65111A6753	SSL	DURIS	Use STANDARD Q#			
DURIS S 5							
GW PSLMS1.EC-GSGU-5L6M-L1M1-65-R18-XX	Q65111A5490	SSL	DURIS	Use STANDARD Q#			
GW PSLMS1.EC-GRGT-6S7T-L1L2-65-R18-XX	Q65111A5494	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KRKT-5R8T-1-150-R18-SA	Q65111A4966	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KTLP-6M7N-1-150-R18-XX	Q65111A5748	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KSKU-6S7S-1-150-R18-XX	Q65111A6151	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KSKU-6V8W-DE-150-R18-XX	Q65111A6169	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KTLP-6S7T-DF-150-R18-XX	Q65111A6350	SSL	DURIS	Use STANDARD Q#			
GW PSLPS1.EC-KULQ-5D8E-1-150-R18-XX	Q65111A7191	SSL	DURIS	Use STANDARD Q#			
GD PLUS							
LB W5AM-GZHX-34-0-350-R18-Z	Q65110A9466	SSL	GD PLUS	Use STANDARD Q#			
LD W5AM-4T1U-34-0-350-R18-Z	Q65111A0261	SSL	GD PLUS	Use STANDARD Q#			
LT W5AM-KXKZ-45-0-350-R18-Z	Q65110A9378	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYKZ-5G7H-0-350-R18-Z	Q65110A9366	SSL	GD PLUS	Use STANDARD Q#			

DISCONTINUED				NEW (REPLACEMENT)			
Device	Ordering Code	Function	Brand	Device	Ordering Code	Function	Brand
LW W5AM-KYKZ-8K8L-0-350-R18-Z	Q65110A9368	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYLX-4H7I-0-350-R18-ZD	Q65110A9381	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYKZ-5G8I-0-350-R18-Z	Q65110A9429	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYLX-78L-0-350-R18-Z	Q65110A9461	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KZLX-6K7L-0-350-R18-Z	Q65110A9530	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYKZ-6K6L-0-350-R18-Z	Q65110A9987	SSL	GD PLUS	Use STANDARD Q#			
LW W5AM-KYKZ-6L-0-350-R18-Z	Q65111A4171	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKZ-5L7N-0-350-R18-ZSB-CK	Q65110A8818	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKZ-5R7S-0-350-R18-Z	Q65110A9389	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKY-4O6Q-0-350-R18-Z	Q65110A9428	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKZ-5L7N-0-350-R18-Z	Q65110A9504	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKZ-4L6N-0-350-R18-Z	Q65110A9773	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKZ-6U7W-0-350-R18-Z	Q65110A9949	SSL	GD PLUS	Use STANDARD Q#			
LCW W5AM-KXKY-6R7T-0-350-R18-ZD	Q65110A9988	SSL	GD PLUS	Use STANDARD Q#			

Products Affected by Product Discontinuation Notification

Number: OS-PD-2016-010

Name: Portfolio streamline : No replacement Parts Planned

Release Date: 4/7/2016

Last Order: 4/7/2016

Last Delivery: 4/7/2016

DISCONTINUED

NEW (REPLACEMENT)

<u>Product</u>	<u>QNumber</u>	<u>QNumber Description</u>	<u>Part Number</u>	<u>Product</u>	<u>QNumber</u>	<u>QNumber Description</u>	<u>Part Number</u>
DURIS S 5		DURIS S 5					
GD PLUS		GD PLUS					
GR DASPA1.	Q65111A6100	GR DASPA1.23-FSFU-45-FJ-100-R18-CK	GR DASPA1.23-FSFU-45-FJ-CK	Use STANDA		Use STANDARD Q#	
GT DASPA1.	Q65111A6099	GT DASPA1.13-GRGT-45-MP-100-R18-CK	GT DASPA1.13-GRGT-45-MP-CK	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A5484	GW CSSRM1.EC-MRMT-5H71-1-700-R18	GW CSSRM1.EC-MRMT-5H71-1	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A5486	GW CSSRM1.EC-MQMS-5O8Q-1-700-R18	GW CSSRM1.EC-MQMS-5O8Q-1	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A5981	GW CSSRM1.EC-MPMR-6S7T-1-700-R18-XX	GW CSSRM1.EC-MPMR-6S7T-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6414	GW CSSRM1.EC-MRMT-5R8T-1-700-R18-XX	GW CSSRM1.EC-MRMT-5R8T-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6415	GW CSSRM1.EC-MQMS-6S7T-1-700-R18-XX	GW CSSRM1.EC-MQMS-6S7T-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6575	GW CSSRM1.EC-MPMR-6V7X-1-700-R18-XX	GW CSSRM1.EC-MPMR-6V7X-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6576	GW CSSRM1.EC-LUMQ-6V7X-1-700-R18-XX	GW CSSRM1.EC-LUMQ-6V7X-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A7066	GW CSSRM1.EC-MRMT-6L7M-1-700-R18-XX	GW CSSRM1.EC-MRMT-6L7M-1-XX	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A7288	GW CSSRM1.EC-LUMQ-6V7W-1-700-R18-XX		Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6958	GW CSSRM1.PC-MUNP-6M7N-1-700-R18-XX	GW CSSRM1.PC-MUNP-6M7N-1	Use STANDA		Use STANDARD Q#	
GW CSSRM	Q65111A6959	GW CSSRM1.PC-MTNP-6R7S-1-700-R18-XX	GW CSSRM1.PC-MTNP-6R7S-1	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A3094	GW DASPA1.EC-HPHR-5H71-1-100-R18-XX	GW DASPA1.EC-HPHR-5H71-1-XX	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A3095	GW DASPA1.EC-GUHQ-5R8T-1-100-R18-XX	GW DASPA1.EC-GUHQ-5R8T-1-XX	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A6116	GW DASPA1.EC-GUHR-5R8T-KN-100-R18-S	GW DASPA1.EC-GUHR-5R8T-KN-SA	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A6117	GW DASPA1.EC-HPHR-5L7N-KN-100-R18-SA	GW DASPA1.EC-HPHR-5L7N-KN-SA	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A6118	GW DASPA1.EC-GUHR-5O8Q-KN-100-R18-S	GW DASPA1.EC-GUHR-5O8Q-KN-S	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A6150	GW DASPA1.EC-GUHQ-5U8X-KN-100-R18-S	GW DASPA1.EC-GUHQ-5U8X-KN-S	Use STANDA		Use STANDARD Q#	
GW DASPA1	Q65111A5934	GW DASPA1.UC-HPHR-5F8G-1-100-R18	GW DASPA1.UC-HPHR-5F8G-1	Use STANDA		Use STANDARD Q#	
GW JDSMS1	Q65111A6482	GW JDSMS1.CC-FQFS-5O8Q-L1N2-120-R18	GW JDSMS1.CC-FQFS-5O8Q-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSMS1	Q65111A6345	GW JDSMS1.EC-FSFU-6M7N-L1N1-120-R18	GW JDSMS1.EC-FSFU-6M7N-L1N1	Use STANDA		Use STANDARD Q#	
GW JDSMS1	Q65111A6715	GW JDSMS1.EC-FSFU-6S6T-L1N2-120-R18	GW JDSMS1.EC-FSFU-6S6T-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSMS1	Q65111A6841	GW JDSMS1.EC-FSFT-6M7N-L1N2-120-R18	GW JDSMS1.EC-FSFT-6M7N-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSMS1	Q65111A6842	GW JDSMS1.EC-FRFS-6U7W-L1N2-120-R18	GW JDSMS1.EC-FRFS-6U7W-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6889	GW JDSRS1.EC-FUGQ-5O8Q-L1N2-120-R18	GW JDSRS1.EC-FUGQ-5O8Q-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6890	GW JDSRS1.EC-FUGQ-5L7N-L1N2-120-R18	GW JDSRS1.EC-FUGQ-5L7N-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6891	GW JDSRS1.EC-FUGQ-5H71-L1N2-120-R18	GW JDSRS1.EC-FUGQ-5H71-L1N2-S	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6892	GW JDSRS1.EC-FUGQ-5E8G-L1N2-120-R18	GW JDSRS1.EC-FUGQ-5E8G-L1N2	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6893	GW JDSRS1.EC-FUGQ-5C8E-L1N2-120-R18	GW JDSRS1.EC-FUGQ-5C8E-L1N2	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

Product	QNumber	QNumber Description	Part Number	Product	QNumber	QNumber Description	Part Number
GW JDSRS1	Q65111A6894	GW JDSRS1.EC-FTGP-5R8T-L1N2-120-R18-	GW JDSRS1.EC-FTGP-5R8T-L1N2-S	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A6895	GW JDSRS1.EC-FSGP-5U8X-L1N2-120-R18-	GW JDSRS1.EC-FSGP-5U8X-L1N2-	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7052	GW JDSRS1.EC-FTGP-5O8Q-L1N2-120-R33	GW JDSRS1.EC-FTGP-5O8Q-L1N2-	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7053	GW JDSRS1.EC-FTGP-5L7N-L1N2-120-R33	GW JDSRS1.EC-FTGP-5L7N-L1N2-L	Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7074	GW JDSRS1.EC-FTGP-6R6S-L1M1-120-R18-		Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7076	GW JDSRS1.EC-FTGP-6O6P-L1M1-120-R33-		Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7077	GW JDSRS1.EC-FTGP-6M6N-L1M1-120-R33-		Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7270	GW JDSRS1.EC-FTGP-6M-1-120-R18-XX		Use STANDA		Use STANDARD Q#	
GW JDSRS1	Q65111A7271	GW JDSRS1.EC-FSFU-6V7V-1-120-R18-XX		Use STANDA		Use STANDARD Q#	
GW PSLMS1	Q65111A5490	GW PSLMS1.EC-GSGU-5L6M-L1M1-65-R18-	GW PSLMS1.EC-GSGU-5L6M-L1M1-	Use STANDA		Use STANDARD Q#	
GW PSLMS1	Q65111A5494	GW PSLMS1.EC-GRGT-6S7T-L1L2-65-R18-X	GW PSLMS1.EC-GRGT-6S7T-L1L2-	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A4966	GW PSLPS1.EC-KRKT-5R8T-1-150-R18-SA	GW PSLPS1.EC-KRKT-5R8T-1-SA	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A5748	GW PSLPS1.EC-KTLP-6M7N-1-150-R18-XX	GW PSLPS1.EC-KTLP-6M7N-1-XX	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A6151	GW PSLPS1.EC-KSKU-6S7S-1-150-R18-XX	GW PSLPS1.EC-KSKU-6S7S-1-XX	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A6169	GW PSLPS1.EC-KSKU-6V8W-DE-150-R18-X	GW PSLPS1.EC-KSKU-6V8W-DE-XX	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A6350	GW PSLPS1.EC-KTLP-6S7T-DF-150-R18-XX	GW PSLPS1.EC-KTLP-6S7T-DF	Use STANDA		Use STANDARD Q#	
GW PSLPS1	Q65111A7191	GW PSLPS1.EC-KULQ-5D8E-1-150-R18-XX		Use STANDA		Use STANDARD Q#	
GY DASPA1	Q65111A6106	GY DASPA1.23-FQFS-45-FJ-100-R18-CK	GY DASPA1.23-FQFS-45-FJ-CK	Use STANDA		Use STANDARD Q#	
LB CPDP	Q65111A0557	LB CPDP-GZHX-34-0-350-R18-CK	LB CPDP-GZHX-34-CK	Use STANDA		Use STANDARD Q#	
LB W5AM	Q65110A9466	LB W5AM-GZHX-34-0-350-R18-Z	LB W5AM-GZHX-34-Z	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3370	LCW CQAR.CC-LTMP-6V7X-L1M1-700-R18-C	LCW CQAR.CC-LTMP-6V7X-L1M1-C	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3427	LCW CQAR.CC-LUNP-6L8M-1-700-R18-SDC-	LCW CQAR.CC-LUNP-6L8M-1-SDC-	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3429	LCW CQAR.CC-LTNP-6P7R-1-700-R18-SDB-	LCW CQAR.CC-LTNP-6P7R-1-SDB-L	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3430	LCW CQAR.CC-LSMU-6S7U-1-700-R18-SDA-	LCW CQAR.CC-LSMU-6S7U-1-SDA-	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3979	LCW CQAR.CC-LSLU-7Q9S-1-700-R18-SEY-	LCW CQAR.CC-LSLU-7Q9S-1-SEY-L	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3988	LCW CQAR.CC-LTMP-6K8M-1-700-R18-SEZ-	LCW CQAR.CC-LTMP-6K8M-1-SEZ-L	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A4063	LCW CQAR.CC-LSLU-6T9V-1-700-R18-SEX-L	LCW CQAR.CC-LSLU-6T9V-1-SEX-L	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A4690	LCW CQAR.CC-MQMT-5O8Q-1-700-R18-D-X	LCW CQAR.CC-MQMT-5O8Q-1-D-X	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A2100	LCW CQAR.EC-MPMR-5R8S-1-700-R18	LCW CQAR.EC-MPMR-5R8S-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A2765	LCW CQAR.EC-MRMT-6H7I-1-700-R18-XX	LCW CQAR.EC-MRMT-6H7I-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A2789	LCW CQAR.EC-MQMS-6M7N-1-700-R18-XX	LCW CQAR.EC-MQMS-6M7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A2899	LCW CQAR.EC-MQMS-5R8T-1-700-R18	LCW CQAR.EC-MQMS-5R8T-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A2904	LCW CQAR.EC-MQMS-5K7M-1-700-R18	LCW CQAR.EC-MQMS-5K7M-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3143	LCW CQAR.EC-MQMS-5U6W-1-700-R18	LCW CQAR.EC-MQMS-5U6W-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3213	LCW CQAR.EC-MSMT-5H6I-1-700-R18-XX	LCW CQAR.EC-MSMT-5H6I-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3479	LCW CQAR.EC-MRMT-5L7N-1-700-R18	LCW CQAR.EC-MRMT-5L7N-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3632	LCW CQAR.EC-MQMS-6U7W-1-700-R18-XX	LCW CQAR.EC-MQMS-6U7W-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3678	LCW CQAR.EC-MRMS-5L7M-1-700-R18	LCW CQAR.EC-MRMS-5L7M-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3679	LCW CQAR.EC-MRMS-6R7T-1-700-R18	LCW CQAR.EC-MRMS-6R7T-1	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3770	LCW CQAR.EC-MPMT-5M7O-1-700-R18-SDX	LCW CQAR.EC-MPMT-5M7O-1-SDX-	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3771	LCW CQAR.EC-MPMT-6V8X-1-700-R18-SDV-	LCW CQAR.EC-MPMT-6V8X-1-SDV-	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3790	LCW CQAR.EC-MSMU-5L6N-L1M1-700-R18-	LCW CQAR.EC-MSMU-5L6N-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3795	LCW CQAR.EC-MPMS-5R8T-1-700-R18-SC-X	LCW CQAR.EC-MPMS-5R8T-1-SC-X	Use STANDA		Use STANDARD Q#	
LCW CQAR	Q65111A3843	LCW CQAR.EC-MPMS-5R8T-1-700-R18-SD-X	LCW CQAR.EC-MPMS-5R8T-1-SD-X	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>	<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>
LCW CQAR.	Q65111A3844	LCW CQAR.EC-MQMT-5H71-1-700-R18-SG-X	LCW CQAR.EC-MQMT-5H71-1-SG-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3845	LCW CQAR.EC-MQMT-5H71-1-700-R18-SH-X	LCW CQAR.EC-MQMT-5H71-1-SH-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3858	LCW CQAR.EC-MQMT-6V7X-L1M1-700-R18-	LCW CQAR.EC-MQMT-6V7X-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3859	LCW CQAR.EC-MRMT-6R7T-L1M1-700-R18-	LCW CQAR.EC-MRMT-6R7T-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3929	LCW CQAR.EC-MRMT-6O7Q-L1M1-700-R18-	LCW CQAR.EC-MRMT-6O7Q-L1M1-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3935	LCW CQAR.EC-MPMT-6S8U-1-700-R18-SDW	LCW CQAR.EC-MPMT-6S8U-1-SDW-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3983	LCW CQAR.EC-MRMT-5L7N-1-700-R18-SET-	LCW CQAR.EC-MRMT-5L7N-1-SET-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3984	LCW CQAR.EC-MPMR-6R8T-1-700-R18-SES-	LCW CQAR.EC-MPMR-6R8T-1-SES-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4035	LCW CQAR.EC-MRMT-5L6N-L1M1-700-R18-	LCW CQAR.EC-MRMT-5L6N-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4036	LCW CQAR.EC-MSMU-6H71-L1M1-700-R18-X	LCW CQAR.EC-MSMU-6H71-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4065	LCW CQAR.EC-MPMR-6U8X-1-700-R18-SER-	LCW CQAR.EC-MPMR-6U8X-1-SER-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4081	LCW CQAR.EC-MPMR-6V7X-1-700-R18-XX	LCW CQAR.EC-MPMR-6V7X-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4083	LCW CQAR.EC-MPMR-6V7X-L1M1-700-R18-	LCW CQAR.EC-MPMR-6V7X-L1M1-C	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4638	LCW CQAR.EC-MRMT-6L7N-L1M1-350-R18-	LCW CQAR.EC-MRMT-6L7N-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4653	LCW CQAR.EC-MRMT-6P7Q-L1M1-700-R18-	LCW CQAR.EC-MRMT-6P7Q-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4654	LCW CQAR.EC-MQMR-6R7T-L1M1-350-R18-	LCW CQAR.EC-MQMR-6R7T-L1M1-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4656	LCW CQAR.EC-MRMT-6S7T-L1M1-700-R18-	LCW CQAR.EC-MRMT-6S7T-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4777	LCW CQAR.EC-MSMU-6S8T-L1MX-700-R18-	LCW CQAR.EC-MSMU-6S8T-L1MX-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4804	LCW CQAR.EC-MPMQ-6V7W-1-700-R18-LL	LCW CQAR.EC-MPMQ-6V7W-1-LL	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5014	LCW CQAR.EC-MTMU-6H71-L1M1-700-R18-X	LCW CQAR.EC-MTMU-6H71-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5359	LCW CQAR.EC-MSMU-6L7N-L1MX-700-R18-	LCW CQAR.EC-MSMU-6L7N-L1MX-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5360	LCW CQAR.EC-MRMT-6R7T-L1MX-700-R18-	LCW CQAR.EC-MRMT-6R7T-L1MX-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5361	LCW CQAR.EC-MQMT-6V7W-L1MX-700-R18-	LCW CQAR.EC-MQMT-6V7W-L1MX-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5362	LCW CQAR.EC-MQMT-6U7W-L1MX-700-R18-	LCW CQAR.EC-MQMT-6U7W-L1MX-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5374	LCW CQAR.EC-MRMT-5M6M-L1MX-700-R18-	LCW CQAR.EC-MRMT-5M6M-L1MX-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5385	LCW CQAR.EC-MQMS-5S8T-1-700-R18	LCW CQAR.EC-MQMS-5S8T-1	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A6567	LCW CQAR.EC-MQMS-6S6T-1-700-R18-Z	LCW CQAR.EC-MQMS-6S6T-1-Z	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A6593	LCW CQAR.EC-MQMR-7V7W-1-700-R18-Z	LCW CQAR.EC-MQMR-7V7W-1-Z	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A1867	LCW CQAR.PC-MSMT-5L7N-1-700-R18-XX	LCW CQAR.PC-MSMT-5L7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3141	LCW CQAR.PC-MTNP-5M7N-1-700-R18-XX	LCW CQAR.PC-MTNP-5M7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3510	LCW CQAR.PC-MTNP-5L7N-1-700-R18-XX	LCW CQAR.PC-MTNP-5L7N-1	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3856	LCW CQAR.PC-MTNP-5H71-L1MX-700-R18	LCW CQAR.PC-MTNP-5H71-L1MX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3862	LCW CQAR.PC-MUNP-5F7G-L1MX-700-R18	LCW CQAR.PC-MUNP-5F7G-L1MX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3878	LCW CQAR.PC-MSMU-5L7N-1-700-R18	LCW CQAR.PC-MSMU-5L7N-1	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A3933	LCW CQAR.PC-MTMU-5L7N-L1MX-700-R18	LCW CQAR.PC-MTMU-5L7N-L1MX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4077	LCW CQAR.PC-MUNQ-6H71-1-700-R18-XX	LCW CQAR.PC-MUNQ-6H71-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4116	LCW CQAR.PC-MTNP-5L7M-1-700-R18-XX	LCW CQAR.PC-MTNP-5L7M-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4153	LCW CQAR.PC-MUNQ-5L7N-1-700-R18-XX	LCW CQAR.PC-MUNQ-5L7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4215	LCW CQAR.PC-MUNQ-5M6N-1-700-R18-ET	LCW CQAR.PC-MUNQ-5M6N-1-ET	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4372	LCW CQAR.PC-MTNP-5L7M-1-700-R18-SB-X	LCW CQAR.PC-MTNP-5L7M-1-SB-X	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4432	LCW CQAR.PC-MTNP-5L7N-1-700-R18-XX	LCW CQAR.PC-MTNP-5L7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4561	LCW CQAR.PC-MTNP-5J7K-1-700-R18-XX	LCW CQAR.PC-MTNP-5J7K-1-XX	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4637	LCW CQAR.PC-MUNQ-6M7N-L2M1-700-R18-	LCW CQAR.PC-MUNQ-6M7N-L2M1-	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4801	LCW CQAR.PC-MUNP-6F7G-1-700-R18-LL	LCW CQAR.PC-MUNP-6F7G-1-LL	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>	<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>
LCW CQAR.	Q65111A4802	LCW CQAR.PC-MTMU-6M7N-1-700-R18-LL	LCW CQAR.PC-MTMU-6M7N-1-LL	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A4803	LCW CQAR.PC-MSMT-6R7S-1-700-R18-LL	LCW CQAR.PC-MSMT-6R7S-1-LL	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5075	LCW CQAR.PC-MUNQ-5H7I-1-700-R18-HB	LCW CQAR.PC-MUNQ-5H7I-1-HB	Use STANDA		Use STANDARD Q#	
LCW CQAR.	Q65111A5953	LCW CQAR.PC-MUNP-7D7E-1-700-R18-XX	LCW CQAR.PC-MUNP-7D7E-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A3481	LCW CR7P.CC-KRKS-6R7S-1-350-R18-XX	LCW CR7P.CC-KRKS-6R7S-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A3654	LCW CR7P.CC-KRKT-6V7X-L1M1-350-R18-C	LCW CR7P.CC-KRKT-6V7X-L1M1-C	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A3774	LCW CR7P.CC-KQLP-6L8M-1-350-R18-SDJ-	LCW CR7P.CC-KQLP-6L8M-1-SDJ-L	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4074	LCW CR7P.CC-KPKU-6S7U-1-350-R18-SDH-	LCW CR7P.CC-KPKU-6S7U-1-SDH-L	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4075	LCW CR7P.CC-KQLP-6P7R-1-350-R18-SDI-L	LCW CR7P.CC-KQLP-6P7R-1	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4094	LCW CR7P.CC-KRKT-6S7T-1-350-R18-XX	LCW CR7P.CC-KRKT-6S7T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4554	LCW CR7P.CC-KRKS-6O7P-1-350-R18-XX	LCW CR7P.CC-KRKS-6O7P-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4713	LCW CR7P.CC-KRKT-6R7T-L1M1-350-R18-X	LCW CR7P.CC-KRKT-6R7T-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4771	LCW CR7P.CC-KTLP-5L6N-1-350-R18-XX	LCW CR7P.CC-KTLP-5L6N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4772	LCW CR7P.CC-KRKT-6V7X-1-350-R18-XX	LCW CR7P.CC-KRKT-6V7X-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.	Q65111A4774	LCW CR7P.CC-KRKT-6M7N-L1MX-350-R18-X	LCW CR7P.CC-KRKT-6M7N-L1MX-X	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A3032	LCW CR7P.EC-KULQ-6R7S-1-350-R18-XX	LCW CR7P.EC-KULQ-6R7S-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A3036	LCW CR7P.EC-KULQ-6L7M-1-350-R18-XX	LCW CR7P.EC-KULQ-6L7M-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A3038	LCW CR7P.EC-KTLP-6U7X-1-350-R18-XX	LCW CR7P.EC-KTLP-6U7X-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A3440	LCW CR7P.EC-KTLP-6V7X-L1M1-350-R18-C	LCW CR7P.EC-KTLP-6V7X-L1M1-CV	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A3572	LCW CR7P.EC-LPLQ-6H7I-1-350-R18	LCW CR7P.EC-LPLQ-6H7I-1	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4093	LCW CR7P.EC-KULQ-6R7S-L1M1-350-R18-C	LCW CR7P.EC-KULQ-6R7S-L1M1-C	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4114	LCW CR7P.EC-LPLR-5H6I-1-350-R18-XX	LCW CR7P.EC-LPLR-5H6I-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4420	LCW CR7P.EC-KSKU-5R8T-1-350-R18-XX	LCW CR7P.EC-KSKU-5R8T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4421	LCW CR7P.EC-KSKU-5L7N-1-350-R18-XX	LCW CR7P.EC-KSKU-5L7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4540	LCW CR7P.EC-KULQ-5S8V-1-350-R18	LCW CR7P.EC-KULQ-5S8V-1	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4542	LCW CR7P.EC-KULP-6O7P-1-350-R18-XX	LCW CR7P.EC-KULP-6O7P-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4545	LCW CR7P.EC-LPLQ-5L6M-1-350-R18-XX	LCW CR7P.EC-LPLQ-5L6M-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4546	LCW CR7P.EC-LPLQ-5H6I-1-350-R18-XX	LCW CR7P.EC-LPLQ-5H6I-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4619	LCW CR7P.EC-KULQ-6R7T-L1M1-350-R18-X	LCW CR7P.EC-KULQ-6R7T-L1M1-X	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4648	LCW CR7P.EC-KTLP-5W8Z-1-350-R18-XX	LCW CR7P.EC-KTLP-5W8Z-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4662	LCW CR7P.EC-LPLQ-6L7N-L1M1-350-R18-X	LCW CR7P.EC-LPLQ-6L7N-L1M1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A4850	LCW CR7P.EC-KULQ-5M6N-1-350-R18-XX	LCW CR7P.EC-KULQ-5M6N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.E	Q65111A5541	LCW CR7P.EC-KULQ-5S8T-1-350-R18	LCW CR7P.EC-KULQ-5S8T-1	Use STANDA		Use STANDARD Q#	
LCW CR7P.P	Q65111A4424	LCW CR7P.PC-LPLR-5E8G-1-350-R18-XX	LCW CR7P.PC-LPLR-5E8G-1-XX	Use STANDA		Use STANDARD Q#	
LCW CR7P.P	Q65111A6558	LCW CR7P.PC-LQLS-5M6N-1-350-R18-XX	LCW CR7P.PC-LQLS-5M6N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3327	LCW CRDP.CC-KRKT-5O8Q-1-350-R18	LCW CRDP.CC-KRKT-5O8Q-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3980	LCW CRDP.CC-KQKS-6T9W-1-350-R18-SEU-	LCW CRDP.CC-KQKS-6T9W-1-SEU-	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3987	LCW CRDP.CC-KQKS-7Q9T-1-350-R18-SEV-	LCW CRDP.CC-KQKS-7Q9T-1-SEV-	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4064	LCW CRDP.CC-KRKT-6K8M-1-350-R18-SEW-	LCW CRDP.CC-KRKT-6K8M-1-SEW-	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4547	LCW CRDP.CC-KRKS-6O7P-1-350-R18-XX	LCW CRDP.CC-KRKS-6O7P-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4549	LCW CRDP.CC-KRKS-6V7W-1-350-R18-XX	LCW CRDP.CC-KRKS-6V7W-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4550	LCW CRDP.CC-KRKS-6S7T-1-350-R18-XX	LCW CRDP.CC-KRKS-6S7T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6556	LCW CRDP.CC-KSKU-5L7M-1-350-R18-XX	LCW CRDP.CC-KSKU-5L7M-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6921	LCW CRDP.CC-KSKU-5J6K-1-350-R18-XX	LCW CRDP.CC-KSKU-5J6K-1-XX	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>	<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>
LCW CRDP.	Q65111A2590	LCW CRDP.EC-KULQ-6R7T-1-350-R18	LCW CRDP.EC-KTLP-6R7T-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A2591	LCW CRDP.EC-KULQ-6L7N-1-350-R18	LCW CRDP.EC-KTLP-6L7N-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A2592	LCW CRDP.EC-KTLP-6U7W-1-350-R18	LCW CRDP.EC-KSKU-6U7W-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A2724	LCW CRDP.EC-KULQ-6O7Q-1-350-R18	LCW CRDP.EC-KTLP-6O7Q-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3030	LCW CRDP.EC-KTLP-6V7W-1-350-R18-XX	LCW CRDP.EC-KTLP-6V7W-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3056	LCW CRDP.EC-KULQ-5S7T-1-350-R18	LCW CRDP.EC-KULQ-5S7T-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3057	LCW CRDP.EC-KULQ-5M7N-1-350-R18	LCW CRDP.EC-KULQ-5M7N-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3060	LCW CRDP.EC-KTLP-6U8W-1-350-R18	LCW CRDP.EC-KTLP-6U8W-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3201	LCW CRDP.EC-LPLR-5L6N-1-350-R18-XX	LCW CRDP.EC-LPLR-5L6N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3536	LCW CRDP.EC-LPLQ-5H6I-1-350-R18	LCW CRDP.EC-LPLQ-5H6I-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3714	LCW CRDP.EC-KULQ-6M7N-1-350-R18	LCW CRDP.EC-KULQ-6M7N-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3715	LCW CRDP.EC-KTLP-6S7T-1-350-R18	LCW CRDP.EC-KTLP-6S7T-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3981	LCW CRDP.EC-KTLP-6R8U-1-350-R18-SEP-L	LCW CRDP.EC-KTLP-6R8U-1-SEP-L	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3982	LCW CRDP.EC-KULQ-5L7N-1-350-R18-SEQ-	LCW CRDP.EC-KULQ-5L7N-1-SEQ-L	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4349	LCW CRDP.EC-KSKU-5S7T-1-350-R18-XX	LCW CRDP.EC-KSKU-5S7T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4387	LCW CRDP.EC-KSKU-5R8T-1-350-R18-XX	LCW CRDP.EC-KSKU-5R8T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4419	LCW CRDP.EC-KSKU-5L7N-1-350-R18-XX	LCW CRDP.EC-KSKU-5L7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4544	LCW CRDP.EC-KULP-6S7T-1-350-R18-XX	LCW CRDP.EC-KULP-6S7T-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4555	LCW CRDP.EC-KULP-6S7T-L2M1-350-R18-S	LCW CRDP.EC-KULP-6S7T-L2M1-S	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4945	LCW CRDP.EC-LPLR-5L7N-1-350-R18-LL	LCW CRDP.EC-LPLR-5L7N-1-LL	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4947	LCW CRDP.EC-KTLP-5U8X-1-350-R18-LL	LCW CRDP.EC-KTLP-5U8X-1-LL	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A5473	LCW CRDP.EC-KULP-6P7Q-1-350-R18-XX	LCW CRDP.EC-KULP-6P7Q-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A5561	LCW CRDP.EC-KTLP-5M7N-1-350-R18-XX	LCW CRDP.EC-KTLP-5M7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6179	LCW CRDP.EC-LQLS-5H7I-1-350-R18	LCW CRDP.EC-LQLS-5H7I-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6603	LCW CRDP.EC-KTLP-7R7S-1-350-R18-Z	LCW CRDP.EC-KTLP-7R7S-1-Z	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6852	LCW CRDP.EC-LPLR-5L7N-L1M1-350-R18-S	LCW CRDP.EC-LPLR-5L7N-L1M1-SA	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A2547	LCW CRDP.PC-LPLR-5L7N-1-350-R18	LCW CRDP.PC-LPLR-5L7N-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A2639	LCW CRDP.PC-LPLR-5J7K-1-350-R18	LCW CRDP.PC-LPLR-5J7K-1	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A3442	LCW CRDP.PC-LSLU-5F7G-1-350-R18-XX	LCW CRDP.PC-LSLU-5F7G-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4423	LCW CRDP.PC-LPLR-5F7F-1-350-R18-XX	LCW CRDP.PC-LPLR-5F7F-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4441	LCW CRDP.PC-LQLS-5M7N-1-350-R18-XX	LCW CRDP.PC-LQLS-5M7N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A4769	LCW CRDP.PC-LRLT-5H7I-L2MX-350-R18-XX	LCW CRDP.PC-LRLT-5H7I-L2MX-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A5276	LCW CRDP.PC-LRLS-6M6N-1-350-R18-Z-XX	LCW CRDP.PC-LRLS-6M6N-1-XX	Use STANDA		Use STANDARD Q#	
LCW CRDP.	Q65111A6372	LCW CRDP.PC-LRLT-6C7D-1-350-R18-XX	LCW CRDP.PC-LRLT-6C7D-1-XX	Use STANDA		Use STANDARD Q#	
LCW JDSI.E	Q65111A3968	LCW JDSI.EC-FSFU-6M7N-L1N2-120-R18-XX	LCW JDSI.EC-FSFU-6M7N-L1N2-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A3092	LCW JNSH.EC-BRBT-6R7T-L1N2-20-R18-Z	LCW JNSH.EC-BRBT-6R7T-L1N2-Z	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A3298	LCW JNSH.EC-BSBT-6R7S-L1M2-20-R18-ZC	LCW JNSH.EC-BSBT-6R7S-L1M2	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A3355	LCW JNSH.EC-BSBU-5M6N-1-20-R18	LCW JNSH.EC-BSBU-5M6N-1	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A3650	LCW JNSH.EC-BRBT-6S7U-L1N2-20-R18-SA	LCW JNSH.EC-BRBT-6S7U-L1N2-SA	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A3659	LCW JNSH.EC-BSBU-6L6N-L1N2-20-R18-XX	LCW JNSH.EC-BSBU-6L6N-L1N2-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A4816	LCW JNSH.EC-BRBT-5R7S-1-20-R18-XX	LCW JNSH.EC-BRBT-5R7S-1-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A4967	LCW JNSH.EC-BTBU-6R7S-L1N2-20-R18-XX	LCW JNSH.EC-BTBU-6R7S-L1N2-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A5052	LCW JNSH.EC-BTBU-5H6I-L1N2-20-R18-XX	LCW JNSH.EC-BTBU-5H6I-L1N2-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A5496	LCW JNSH.EC-BTBU-6R7S-L1M2-20-R18-XX	LCW JNSH.EC-BTBU-6R7S-L1M2-XX	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

Product	QNumber	QNumber Description	Part Number	Product	QNumber	QNumber Description	Part Number
LCW JNSH.E	Q65111A6534	LCW JNSH.EC-BTCP-6R6S-L2M2-20-R18-XX	LCW JNSH.EC-BTCP-6R6S-L2M2-XX	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A6977	LCW JNSH.EC-BTCP-5H7I-L1M2-20-R18-SB-	LCW JNSH.EC-BTCP-5H7I-L1M2-SB-	Use STANDA		Use STANDARD Q#	
LCW JNSH.E	Q65111A7285	LCW JNSH.EC-BRBT-6U6X-1-20-R18-XX		Use STANDA		Use STANDARD Q#	
LCW JNSH.P	Q65111A5854	LCW JNSH.PC-BUCQ-5L8N-1-20-R18	LCW JNSH.PC-BUCQ-5L8N-1	Use STANDA		Use STANDARD Q#	
LCW JNSH.P	Q65111A5855	LCW JNSH.PC-BUCQ-5H8I-1-20-R18	LCW JNSH.PC-BUCQ-5H8I-1	Use STANDA		Use STANDARD Q#	
LCW JNSH.P	Q65111A6184	LCW JNSH.PC-BUCQ-6H7I-1-20-R18-XX	LCW JNSH.PC-BUCQ-6H7I-1-XX	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A8818	LCW W5AM-KXKZ-5L7N-0-350-R18-ZSB-CK	LCW W5AM-KXKZ-5L7N-ZSB-CK	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9389	LCW W5AM-KXKZ-5R7S-0-350-R18-Z	LCW W5AM-KXKZ-5R7S-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9428	LCW W5AM-KXKY-4O6Q-0-350-R18-Z	LCW W5AM-KXKY-4O6Q-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9504	LCW W5AM-KXKZ-5L7N-0-350-R18-Z	LCW W5AM-KXKZ-5L7N-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9773	LCW W5AM-KXKZ-4L6N-0-350-R18-Z	LCW W5AM-KXKZ-4L6N-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9949	LCW W5AM-KXKZ-6U7W-0-350-R18-Z	LCW W5AM-KXKZ-6U7W-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65110A9988	LCW W5AM-KXKY-6R7T-0-350-R18-ZD	LCW W5AM-KXKY-6R7T-ZD	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0037	LCW W5AM-KXKY-5Q8S-0-350-R18-Z	LCW W5AM-KXKY-5Q8S-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0109	LCW W5AM-KYKZ-5K7M-0-350-R18-Z	LCW W5AM-KYKZ-5K7M-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0458	LCW W5AM-KXKZ-5U8X-0-350-R18-Z	LCW W5AM-KXKZ-5U8X-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0571	LCW W5AM-KYKZ-5L7M-0-350-R18-Z	LCW W5AM-KYKZ-5L7M-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0625	LCW W5AM-KXKY-5R8T-0-350-R33-Z	LCW W5AM-KXKY-5R8T-L-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0626	LCW W5AM-KYKZ-5L7N-0-350-R33-Z	LCW W5AM-KYKZ-5L7N-L-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0661	LCW W5AM-KYKZ-5R8T-0-350-R18-Z-XX	LCW W5AM-KYKZ-5R8T-XX	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0721	LCW W5AM-KYKZ-5R7T-0-350-R18-Z-XX	LCW W5AM-KYKZ-5R7T-Z-XX	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A0853	LCW W5AM-KXKY-6S7T-0-350-R18-Z-XX	LCW W5AM-KXKY-6S7T-Z-XX	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A1100	LCW W5AM-KXKY-7R9T-0-350-R18-Z	LCW W5AM-KXKY-7R9T-R18-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A1101	LCW W5AM-KYKZ-6L8N-0-350-R18-Z	LCW W5AM-KYKZ-6L8N-Z	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A1620	LCW W5AM-KYKZ-6R7T-0-350-R18-Z-XX	LCW W5AM-KYKZ-6R7T-XX	Use STANDA		Use STANDARD Q#	
LCW W5AM	Q65111A1775	LCW W5AM-KYLX-4H8I-0-350-R18-Z	LCW W5AM-KYLX-4H8I-R18-Z	Use STANDA		Use STANDARD Q#	
LD CQ7P	Q65111A4159	LD CQ7P-2U3U-W2-1-350-R18-Z	LD CQ7P-2U3U-W2-1	Use STANDA		Use STANDARD Q#	
LD CQ7P	Q65111A4962	LD CQ7P-2U3U-2-1-350-R18-Z-XX	LD CQ7P-2U3U-2-1-Z-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A3238	LD CQAR-APAQ-23-L1M1-700-R18-XX	LD CQAR-APAQ-23-L1M1-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A4347	LD CQAR-APAQ-2-L1MX-700-R18-XX	LD CQAR-APAQ-2-L1MX-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A4348	LD CQAR-APAQ-2-L1M1-700-R18-XX	LD CQAR-APAQ-2-L1M1-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A4356	LD CQAR-AQAR-23-L1MX-700-R18-XX	LD CQAR-AQAR-23-L1MX-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5050	LD CQAR-APAR-34-1-700-R18	LD CQAR-APAR-34-1	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5190	LD CQAR-AQAR-23-L1M1-700-R33-XX	LD CQAR-AQAR-23-L1M1-L-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5191	LD CQAR-AQAR-2-L1M1-700-R33-XX	LD CQAR-AQAR-2-L1M1-L-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5193	LD CQAR-APAQ-2-L1M1-700-R33-XX	LD CQAR-APAQ-2-L1M1-L-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5587	LD CQAR-AQAR-2-L1-700-R33-XX	LD CQAR-AQAR-2-L1-700-R33-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A5588	LD CQAR-APAQ-2-L1-700-R33-XX	LD CQAR-APAQ-2-L1-700-R33-XX	Use STANDA		Use STANDARD Q#	
LD CQAR	Q65111A6175	LD CQAR-APAQ-3-L1M1-700-R33-XX	LD CQAR-APAQ-3-L1M1-XX	Use STANDA		Use STANDARD Q#	
LD CQDP	Q65111A1969	LD CQDP-2U4U-23-1-350-R18-K	LD CQDP-2U4U-23-1-K	Use STANDA		Use STANDARD Q#	
LD CQDP	Q65111A4571	LD CQDP-2U3U-23-34-350-R18-SHR	LD CQDP-2U3U-23-34-SHR	Use STANDA		Use STANDARD Q#	
LD CQDP	Q65111A4627	LD CQDP-2U3U-W2-34-350-R18-K	LD CQDP-2U3U-W2-34	Use STANDA		Use STANDARD Q#	
LD CQDP	Q65111A6589	LD CQDP-3U4U-24-1-350-R18-XX	LD CQDP-3U4U-24-1-XX	Use STANDA		Use STANDARD Q#	
LD W5AM	Q65111A0261	LD W5AM-4T1U-34-0-350-R18-Z	LD W5AM-4T1U-34-Z	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>	<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>
LR CP7P	Q65111A6901	LR CP7P-JTJU-1-0-350-R18	LR CP7P-JTJU-1	Use STANDA		Use STANDARD Q#	
LT CPDP	Q65111A0948	LT CPDP-KYKZ-45-0-350-R18-CK	LT CPDP-KYKZ-45-CK	Use STANDA		Use STANDARD Q#	
LT CPDP	Q65111A5051	LT CPDP-KZLX-56-0-350-R18	LT CPDP-KZLX-56	Use STANDA		Use STANDARD Q#	
LT W5AM	Q65110A9378	LT W5AM-KXKZ-45-0-350-R18-Z	LT W5AM-KXKZ-45-Z	Use STANDA		Use STANDARD Q#	
LUW CQ7P	Q65111A1640	LUW CQ7P-LQLS-5C6F-1-350-R18-K-XX	LUW CQ7P-LQLS-5C6F-1-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2539	LUW CQAR-MTNP-JPJQ-1-700-R18	LUW CQAR-MTNP-JPJQ-1	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2567	LUW CQAR-MUNQ-MGMS-1-700-R18-SC-XX	LUW CQAR-MUNQ-MGMS-1-SC-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2568	LUW CQAR-MUNQ-MGMS-1-700-R18-SD-XX	LUW CQAR-MUNQ-MGMS-1-SD-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2733	LUW CQAR-MTNP-HPJR-1-700-R18	LUW CQAR-MTNP-HPJR-1	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2735	LUW CQAR-MTNP-HPHR-1-700-R18	LUW CQAR-MTNP-HPHR-1	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A2965	LUW CQAR-MTNP-JPJR-M1MX-700-R18-XX	LUW CQAR-MTNP-JPJR-M1MX-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A3049	LUW CQAR-MUNQ-JPJQ-1-700-R18-XX	LUW CQAR-MUNQ-JPJQ-1-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A3544	LUW CQAR-NPNR-KPLP-1-700-R18	LUW CQAR-NPNR-KPLP-1	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A3660	LUW CQAR-NPNR-MMMN-1-700-R18-XX	LUW CQAR-NPNR-MMMN-1-R18-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A4376	LUW CQAR-NPNR-JPJQ-1-700-R18-XX	LUW CQAR-NPNR-JPJQ-1-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A4799	LUW CQAR-MUNQ-JPJR-L1M1-700-R18-XX	LUW CQAR-MUNQ-JPJR-L1M1-XX	Use STANDA		Use STANDARD Q#	
LUW CQAR	Q65111A6601	LUW CQAR-MUNQ-GPGR-1-700-R18-XX	LUW CQAR-MUNQ-GPGR-1-XX	Use STANDA		Use STANDARD Q#	
LUW CRDP	Q65111A4147	LUW CRDP-LRLT-HPJR-L1M1-350-R18-XX	LUW CRDP-LRLT-HPJR-L1M1-XX	Use STANDA		Use STANDARD Q#	
LUW CRDP	Q65111A4319	LUW CRDP-LRLT-MMMP-1-350-R18	LUW CRDP-LRLT-MMMP-1	Use STANDA		Use STANDARD Q#	
LUW CRDP	Q65111A4338	LUW CRDP-LRLT-HQHR-1-350-R18	LUW CRDP-LRLT-HQHR-1	Use STANDA		Use STANDARD Q#	
LUW CRDP	Q65111A4758	LUW CRDP-LQLS-HPJQ-1-350-R18-XX	LUW CRDP-LQLS-HPJQ-1-XX	Use STANDA		Use STANDARD Q#	
LUW CRDP	Q65111A5614	LUW CRDP-LRLS-HQ-1-350-R18-XX	LUW CRDP-LRLS-HQ-1-XX	Use STANDA		Use STANDARD Q#	
LUW JNSH.E	Q65111A3025	LUW JNSH.EC-BBSU-5C8E-L1M2-20-R18	LUW JNSH.EC-BBSU-5C8E-L1M2	Use STANDA		Use STANDARD Q#	
LUW JNSH.E	Q65111A4139	LUW JNSH.EC-BTCP-5E8G-1-20-R18-XX	LUW JNSH.EC-BTCP-5E8G-1-XX	Use STANDA		Use STANDARD Q#	
LUW JNSH.E	Q65111A4742	LUW JNSH.EC-BTCP-6E7G-L1N2-120-R18-X	LUW JNSH.EC-BTCP-6E7G-L1N2	Use STANDA		Use STANDARD Q#	
LUW JNSH.E	Q65111A6405	LUW JNSH.EC-BTCP-5C7E-L1M1-20-R18-XX	LUW JNSH.EC-BTCP-5C7E-L1M1-XX	Use STANDA		Use STANDARD Q#	
LUW JNSH.P	Q65111A4732	LUW JNSH.PC-BTCQ-6C7E-L1N2-20-R18-XX	LUW JNSH.PC-BTCQ-6C7E-L1N2-XX	Use STANDA		Use STANDARD Q#	
LUW JNSH.P	Q65111A6753	LUW JNSH.PC-BUCQ-5C8D-1-20-R18-XX	LUW JNSH.PC-BUCQ-5C8D-1-XX	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9430	LUW W5AM-KZLX-6E8F-0-350-R18-ZN	LUW W5AM-KZLX-6E8F-ZN	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9577	LUW W5AM-KZLY-5E8F-0-350-R18-ZN	LUW W5AM-KZLY-5E8F-ZN	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9578	LUW W5AM-KZLY-5E8G-0-350-R18-ZN	LUW W5AM-KZLY-5E8G-ZN	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9607	LUW W5AM-LXLY-6P7Q-0-350-R18-Z	LUW W5AM-LXLY-6P7Q-Z	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9639	LUW W5AM-LXLY-7P7R-0-350-R33-XX	LUW W5AM-LXLY-7P7R-L-XX	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65110A9996	LUW W5AM-KYLX-4A7C-0-350-R18-ZN	LUW W5AM-KYLX-4A7C-ZN	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65111A0164	LUW W5AM-KZLY-6E8F-0-350-R18-ZN	LUW W5AM-KZLY-6E8F-0-350-R18-	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65111A0617	LUW W5AM-LXLY-6P7R-0-350-R33-Z	LUW W5AM-LXLY-6P7R-L-Z	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65111A0858	LUW W5AM-KYKZ-5C6E-0-350-R18-ZN-XX	LUW W5AM-KYKZ-5C6E-ZN-XX	Use STANDA		Use STANDARD Q#	
LUW W5AM	Q65111A1528	LUW W5AM-KYLX-5B6C-0-350-R18-Z-XX	LUW W5AM-KYLX-5B6C-Z-XX	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9366	LW W5AM-KYKZ-5G7H-0-350-R18-Z	LW W5AM-KYKZ-5G7H-Z	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9368	LW W5AM-KYKZ-8K8L-0-350-R18-Z	LW W5AM-KYKZ-8K8L-Z	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9381	LW W5AM-KYLX-4H7I-0-350-R18-ZD	LW W5AM-KYLX-4H7I-0-350-R18-ZD	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9429	LW W5AM-KYKZ-5G8I-0-350-R18-Z	LW W5AM-KYKZ-5G8I-Z	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9461	LW W5AM-KYLX-78L-0-350-R18-Z	LW W5AM-KYLX-78L-Z	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65110A9530	LW W5AM-KZLX-6K7L-0-350-R18-Z	LW W5AM-KZLX-6K7L-Z	Use STANDA		Use STANDARD Q#	

DISCONTINUED

NEW (REPLACEMENT)

<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>	<i>Product</i>	<i>QNumber</i>	<i>QNumber Description</i>	<i>Part Number</i>
LW W5AM	Q65110A9987	LW W5AM-KYKZ-6K6L-0-350-R18-Z	LW W5AM-KYKZ-6K6L-Z	Use STANDA		Use STANDARD Q#	
LW W5AM	Q65111A4171	LW W5AM-KYKZ-6L-0-350-R18-Z	LW W5AM-KYKZ-6L	Use STANDA		Use STANDARD Q#	
LY CPDP	Q65111A4569	LY CPDP-JRJT-35-0-350-R18-SHR	LY CPDP-JRJT-35-SHR	Use STANDA		Use STANDARD Q#	
OSLON SQU		OSLON SQUARE					
OSLON SSL		OSLON SSL 80/150					