



Mini Tracking Pad Model 210

Quick Start Guide (78–8129-3901-1)

To install your Mini Tracking Pad Model 210, complete the following steps.

1. Go to www.3m.com/rfidtools.

2. Click **RFID Reader Driver Install Tool**.

This application installs the required drivers on your computer.

3. Plug the Mini Tracking Pad Model 210 into an available USB port on your computer using the cable provided.

The hardware connects with the drivers (this may take a few moments). The reader pad lights turn on when the reader is ready to use.

4. Click **RFID Reader Demo Tool**.

Use this application to connect to and test the RFID reader pad.

To use the Demo tool, your system must meet the following requirement:

- Microsoft® Windows XP, Service Pack 2
- Microsoft® Windows Vista®, Service Pack 1

5. Click **RFID Reader Protocol Spec**.

This document contains the information required to begin developing software for the reader.



For support, contact 3M Software Support at ft-software-support@mmm.com.

Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

Copyright © 2009 3M. All rights reserved.