



Product Change Notification

Date Issued :	March 28, 2023	PCN Number :	513478
Reason for Change :	Retraction		
Description of Change :	This notification is to advise you of a modification to a previously issued PCN. Please refer to the information below for details regarding the amendment		
Reason for Short Notice :	Supplier Constraints		
Assessment of Change :	No change to parts - Form/Fit/Function		
Planned Implementation Date :	March 31, 2023		
Sample Availability Date:	March 20, 2023		
Internal Molex Qualification Date :	March 20, 2023		
Last date to request Samples by Customer :	March 20, 2023		
Traceability Code Markings / Date :	Date code		

Before Picture

Overview

PCN	Resin Material	Molex Product
513478	Retraction PCN	043045, 043650 series

- This is to notify previously issued PCN 512489 cancelation by retraction PCN 513478
- The previous issued PCN 512489 will be not implemented due to disagreement by impacted customers
- Part list as below attachment
- This is retraction is effective immediately

You may address inquires regarding this PCN by clicking on the below link

mailto:pcn_coordinator@molex.com?subject=PCN_Notification:513478

or contact your Local Sales Engineer.

Note: While responding, please retain " PCN Notification : **PCN Notification: 513478** " in the e-mail Subject line for faster response.

[Molex, LLC](#)

2222 Wellington Court

Lisle, IL 60532

TEL (800) 786-6539

www.molex.com

PCN No Part List

513478 [0430450200](#)
513478 [0430450201](#)
513478 [0430450202](#)
513478 [0430450206](#)
513478 [0430450209](#)
513478 [0430450211](#)
513478 [0430450212](#)
513478 [0430450213](#)
513478 [0430450214](#)
513478 [0430450215](#)
513478 [0430450216](#)
513478 [0430450218](#)
513478 [0430450219](#)
513478 [0430450220](#)
513478 [0430450221](#)
513478 [0430450222](#)
513478 [0430450223](#)
513478 [0430450224](#)
513478 [0430450225](#)
513478 [0430450226](#)
513478 [0430450227](#)
513478 [0430450228](#)
513478 [0430450229](#)
513478 [0430450278](#)
513478 [0430450283](#)
513478 [0430450400](#)
513478 [0430450401](#)
513478 [0430450402](#)
513478 [0430450406](#)
513478 [0430450407](#)
513478 [0430450408](#)
513478 [0430450409](#)
513478 [0430450410](#)
513478 [0430450411](#)
513478 [0430450412](#)
513478 [0430450413](#)
513478 [0430450414](#)
513478 [0430450415](#)
513478 [0430450416](#)
513478 [0430450417](#)
513478 [0430450418](#)
513478 [0430450419](#)
513478 [0430450420](#)
513478 [0430450421](#)
513478 [0430450422](#)

513478 [0430450423](#)
513478 [0430450424](#)
513478 [0430450425](#)
513478 [0430450426](#)
513478 [0430450427](#)
513478 [0430450428](#)
513478 [0430450429](#)
513478 [0430450469](#)
513478 [0430450483](#)
513478 [0430450488](#)
513478 [0430450491](#)
513478 [0430450498](#)
513478 [0430450504](#)
513478 [0430450506](#)
513478 [0430450518](#)
513478 [0430450523](#)
513478 [0430450600](#)
513478 [0430450601](#)
513478 [0430450602](#)
513478 [0430450606](#)
513478 [0430450607](#)
513478 [0430450608](#)
513478 [0430450609](#)
513478 [0430450610](#)
513478 [0430450611](#)
513478 [0430450612](#)
513478 [0430450613](#)
513478 [0430450614](#)
513478 [0430450615](#)
513478 [0430450616](#)
513478 [0430450617](#)
513478 [0430450618](#)
513478 [0430450619](#)
513478 [0430450620](#)
513478 [0430450621](#)
513478 [0430450622](#)
513478 [0430450623](#)
513478 [0430450624](#)
513478 [0430450625](#)
513478 [0430450626](#)
513478 [0430450627](#)
513478 [0430450628](#)
513478 [0430450629](#)
513478 [0430450658](#)
513478 [0430450677](#)
513478 [0430450678](#)

513478 [0430450679](#)
513478 [0430450683](#)
513478 [0430450691](#)
513478 [0430450703](#)
513478 [0430450704](#)
513478 [0430450721](#)
513478 [0430451000](#)
513478 [0430451001](#)
513478 [0430451002](#)
513478 [0430451006](#)
513478 [0430451007](#)
513478 [0430451008](#)
513478 [0430451009](#)
513478 [0430451010](#)
513478 [0430451011](#)
513478 [0430451012](#)
513478 [0430451013](#)
513478 [0430451014](#)
513478 [0430451015](#)
513478 [0430451016](#)
513478 [0430451017](#)
513478 [0430451018](#)
513478 [0430451019](#)
513478 [0430451020](#)
513478 [0430451021](#)
513478 [0430451022](#)
513478 [0430451023](#)
513478 [0430451024](#)
513478 [0430451025](#)
513478 [0430451026](#)
513478 [0430451027](#)
513478 [0430451028](#)
513478 [0430451029](#)
513478 [0430451049](#)
513478 [0430451083](#)
513478 [0430451093](#)
513478 [0430451105](#)
513478 [0430451200](#)
513478 [0430451201](#)
513478 [0430451202](#)
513478 [0430451206](#)
513478 [0430451207](#)
513478 [0430451208](#)
513478 [0430451209](#)
513478 [0430451210](#)
513478 [0430451211](#)

[513478 0430451212](#)
[513478 0430451213](#)
[513478 0430451214](#)
[513478 0430451215](#)
[513478 0430451216](#)
[513478 0430451217](#)
[513478 0430451218](#)
[513478 0430451219](#)
[513478 0430451220](#)
[513478 0430451221](#)
[513478 0430451222](#)
[513478 0430451223](#)
[513478 0430451224](#)
[513478 0430451225](#)
[513478 0430451226](#)
[513478 0430451227](#)
[513478 0430451228](#)
[513478 0430451229](#)
[513478 0430451278](#)
[513478 0430451299](#)
[513478 0430451303](#)
[513478 0430451307](#)
[513478 0430451319](#)
[513478 0430451400](#)
[513478 0430451401](#)
[513478 0430451402](#)
[513478 0430451406](#)
[513478 0430451407](#)
[513478 0430451408](#)
[513478 0430451409](#)
[513478 0430451410](#)
[513478 0430451411](#)
[513478 0430451412](#)
[513478 0430451413](#)
[513478 0430451414](#)
[513478 0430451415](#)
[513478 0430451416](#)
[513478 0430451417](#)
[513478 0430451418](#)
[513478 0430451419](#)
[513478 0430451420](#)
[513478 0430451421](#)
[513478 0430451422](#)
[513478 0430451423](#)
[513478 0430451424](#)
[513478 0430451425](#)

513478 [0430451426](#)
513478 [0430451427](#)
513478 [0430451428](#)
513478 [0430451429](#)
513478 [0430451800](#)
513478 [0430451801](#)
513478 [0430451802](#)
513478 [0430451806](#)
513478 [0430451807](#)
513478 [0430451809](#)
513478 [0430451811](#)
513478 [0430451812](#)
513478 [0430451813](#)
513478 [0430451814](#)
513478 [0430451815](#)
513478 [0430451817](#)
513478 [0430451818](#)
513478 [0430451819](#)
513478 [0430451820](#)
513478 [0430451821](#)
513478 [0430451822](#)
513478 [0430451824](#)
513478 [0430451826](#)
513478 [0430451827](#)
513478 [0430451828](#)
513478 [0430451829](#)
513478 [0430451902](#)
513478 [0430452000](#)
513478 [0430452001](#)
513478 [0430452002](#)
513478 [0430452006](#)
513478 [0430452007](#)
513478 [0430452008](#)
513478 [0430452009](#)
513478 [0430452010](#)
513478 [0430452011](#)
513478 [0430452012](#)
513478 [0430452013](#)
513478 [0430452014](#)
513478 [0430452015](#)
513478 [0430452016](#)
513478 [0430452018](#)
513478 [0430452019](#)
513478 [0430452020](#)
513478 [0430452021](#)
513478 [0430452022](#)

513478 [0430452023](#)
513478 [0430452024](#)
513478 [0430452025](#)
513478 [0430452026](#)
513478 [0430452027](#)
513478 [0430452028](#)
513478 [0430452029](#)
513478 [0430452200](#)
513478 [0430452201](#)
513478 [0430452202](#)
513478 [0430452206](#)
513478 [0430452207](#)
513478 [0430452208](#)
513478 [0430452209](#)
513478 [0430452210](#)
513478 [0430452212](#)
513478 [0430452213](#)
513478 [0430452214](#)
513478 [0430452215](#)
513478 [0430452216](#)
513478 [0430452217](#)
513478 [0430452218](#)
513478 [0430452219](#)
513478 [0430452220](#)
513478 [0430452221](#)
513478 [0430452223](#)
513478 [0430452224](#)
513478 [0430452225](#)
513478 [0430452227](#)
513478 [0430452228](#)
513478 [0430452318](#)
513478 [0430452400](#)
513478 [0430452401](#)
513478 [0430452402](#)
513478 [0430452406](#)
513478 [0430452407](#)
513478 [0430452409](#)
513478 [0430452410](#)
513478 [0430452411](#)
513478 [0430452412](#)
513478 [0430452413](#)
513478 [0430452414](#)
513478 [0430452415](#)
513478 [0430452416](#)
513478 [0430452417](#)
513478 [0430452418](#)

513478 [0430452419](#)
513478 [0430452420](#)
513478 [0430452421](#)
513478 [0430452422](#)
513478 [0430452423](#)
513478 [0430452424](#)
513478 [0430452425](#)
513478 [0430452426](#)
513478 [0430452427](#)
513478 [0430452428](#)
513478 [0430452429](#)
513478 [0430452478](#)
513478 [0430454409](#)
513478 [0430454410](#)
513478 [0430454610](#)
513478 [0430454611](#)
513478 [0430455420](#)
513478 [0430455602](#)
513478 [0430455614](#)
513478 [0430456814](#)
513478 [0430458010](#)
513478 [0430458011](#)
513478 [0430458210](#)
513478 [0430458211](#)
513478 [0430458410](#)
513478 [0430459422](#)
513478 [0436500200](#)
513478 [0436500201](#)
513478 [0436500202](#)
513478 [0436500203](#)
513478 [0436500204](#)
513478 [0436500205](#)
513478 [0436500209](#)
513478 [0436500210](#)
513478 [0436500211](#)
513478 [0436500212](#)
513478 [0436500213](#)
513478 [0436500214](#)
513478 [0436500221](#)
513478 [0436500223](#)
513478 [0436500224](#)
513478 [0436500225](#)
513478 [0436500226](#)
513478 [0436500244](#)
513478 [0436500300](#)
513478 [0436500301](#)

513478 [0436500302](#)
513478 [0436500303](#)
513478 [0436500304](#)
513478 [0436500305](#)
513478 [0436500309](#)
513478 [0436500310](#)
513478 [0436500312](#)
513478 [0436500313](#)
513478 [0436500314](#)
513478 [0436500322](#)
513478 [0436500324](#)
513478 [0436500325](#)
513478 [0436500326](#)
513478 [0436500403](#)
513478 [0436500404](#)
513478 [0436500405](#)
513478 [0436500409](#)
513478 [0436500410](#)
513478 [0436500411](#)
513478 [0436500412](#)
513478 [0436500413](#)
513478 [0436500414](#)
513478 [0436500421](#)
513478 [0436500422](#)
513478 [0436500423](#)
513478 [0436500424](#)
513478 [0436500425](#)
513478 [0436500426](#)
513478 [0436500503](#)
513478 [0436500504](#)
513478 [0436500505](#)
513478 [0436500510](#)
513478 [0436500512](#)
513478 [0436500513](#)
513478 [0436500514](#)
513478 [0436500522](#)
513478 [0436500524](#)
513478 [0436500525](#)
513478 [0436500603](#)
513478 [0436500604](#)
513478 [0436500609](#)
513478 [0436500610](#)
513478 [0436500612](#)
513478 [0436500613](#)
513478 [0436500614](#)
513478 [0436500624](#)

513478 [0436500625](#)
513478 [0436500657](#)
513478 [0436500703](#)
513478 [0436500709](#)
513478 [0436500710](#)
513478 [0436500712](#)
513478 [0436500713](#)
513478 [0436500714](#)
513478 [0436500724](#)
513478 [0436500725](#)
513478 [0436500803](#)
513478 [0436500804](#)
513478 [0436500809](#)
513478 [0436500812](#)
513478 [0436500813](#)
513478 [0436500814](#)
513478 [0436500824](#)
513478 [0436500825](#)
513478 [0436501003](#)
513478 [0436501009](#)
513478 [0436501010](#)
513478 [0436501012](#)
513478 [0436501013](#)
513478 [0436501014](#)
513478 [0436501024](#)
513478 [0436501212](#)
513478 [0436501213](#)
513478 [0436501225](#)
513478 [0436501304](#)
513478 [0436501314](#)
513478 [0436501704](#)
513478 [0436502704](#)
513478 [0795405002](#)
513478 [0795405003](#)
513478 [0795405015](#)
513478 [1532450001](#)
513478 [1532830001](#)