

User Registration

Register today to create your account on Silabs.com. Your personalized profile allows you to receive technical document updates, new product announcements, “how-to” and design documents, product change notices (PCN) and other valuable content available only to registered users. <http://www.silabs.com/profile>

Bulletin Date: 2/13/2014		Bulletin Effective Date: 2/13/2014	
Title: C8051F99x/8x Errata Update			
Originator: Shahram Tadayon		Phone: 512-428-1698	Dept: Marketing
Customer Contact: Kathy Haggar		Phone: 512-532-5261	Dept: Sales
Bulletin Details			
Description: C8051F99x/8x Revision A/B Errata has been updated and is available at www.silabs.com . Please contact your Silicon Labs sales representative if you have questions. A list of Silicon Labs representatives is available at www.silabs.com .			
Reason: There are two additional erratum to the C8051F99x/8x Revision A/B errata. <ul style="list-style-type: none"> • The POR Supply Monitor should not be disabled if the supply voltage is greater than 2.4 V • The flash read signal on Revision B devices will deactivate early if the write to the CRC0CN register that starts the automatic flash CRC operation is not followed by a single cycle instruction. Please see C8051F99x/8x Errata for more detailed description, impact, and work around. Please contact your Silicon Labs sales representative if you have questions. A list of Silicon Labs representatives is available at www.silabs.com .			
Product Identification: The following orderable part numbers are affected: C8051F980-GM C8051F981-GM C8051F982-GM C8051F983-GM C8051F985-GM C8051F986-GM C8051F986-GU C8051F987-GM C8051F987-GU C8051F988-GM C8051F988-GU C8051F989-GM C8051F989-GU C8051F990-GM C8051F991-GM C8051F996-GM C8051F996-GU C8051F997-GM C8051F997-GU			
Note: The part numbers above include tape and reel variants which are denoted with an “R” at the end of the orderable part number.			

This change is considered a minor change which does not affect form, fit, function, quality, or reliability. The information is being provided as a customer courtesy.

Please contact your local Silicon Laboratories sales representative with any questions about this notification. A list of Silicon Laboratories sales representatives may be found at www.silabs.com

Customer Actions Needed:

None. Please contact your Silicon Labs sales representative if you have questions. A list of Silicon Labs representatives is available at www.silabs.com.