



Note: Please refer to the included Quick Start Guide to set your device faster.

1. When you unbox the Mimic GO, it will do a light show and play a welcome ringtone. If you do not hear the ringtone or see the light, please re-charge your Mimic GO.

2. Download the Smart Mimic application on your mobile phone from the App Store or Google Play Store.

3. Sign-in to the App using any of the privacy friendly login options.

4. Hold the Mimic GO and your phone near each other and press the "Connect" button that automatically slides up on the App display.

5. Press the "Bell" icon on the main screen of the App to confirm that your Mimic GO is connected.

6. To test it, place your Mimic GO on a laptop or backpack. Use the 'Belongings' mode in the App to activate your Mimic GO. Moving the laptop or backpack will sound the alarm.

Caution: Some people may find the alarm volume high.

1. Make sure Bluetooth is on and phone is connected to the Internet while setting up your Mimic GO.


2. To make sure the Mimic GO is charged press the button on the back. A green light should light up.

3. Recharge the Mimic GO by connecting it to a computer or a UL-listed USB wall charger using the included micro-USB cable.

4. To restart the Mimic GO, please push the button on the back of the Mimic GO for 15 seconds until the light starts flashing. After that the restart will be complete.

5. You can hard reset your Mimic GO by using the pinhole reset button. (see image below) Just press it once with the help of a thin tool. Once it resets it will start flashing lights.

6. If you need further assistance or have any questions please contact us via our website.



Attachment - Mimic HUG

Use Mimic HUG to stick your Mimic GO onto just about anything. Mimic HUG comes in 2 types. Black (*HUG Anytime*) and Red (*HUG Forever*)

You can use *HUG Anytime (black)* on doors, windows or any smooth surface. Press firmly to fix it in place. Pull firmly to remove.

You can use *HUG Forever (red)* to stick permanently to drywall, concrete, unfinished wood and most other flat surfaces. Caution: Permanent Adhesive

WARNING: While removing *HUG Forever*, underlying surface damage may occur. Smart Mimic is not responsible for any damage as a result of user installation choices.

Operation Guide

Note: Refer to the included Quick Start Guide to set your Mimic GO up faster.

1. Peel off the backing before using your Mimic HUG. Caution: The peel-off backing can be a choking hazard. Dispose of the backing safely.

2. Use a clean cloth or wipes to ensure that the surface is free of dust or grime. Then press your HUG firmly against the surface.


3. Press your Mimic GO firmly on the HUG to attach it. To remove Mimic GO pull away from the HUG firmly. (see image below)

4. To move *HUG Anytime* just grasp the edges firmly and pull and twist to lift edge from the surface. Lift to remove. To remove or move the *HUG Forever* see number 6.

5. Wipe or wash the adhesive back of your *HUG Anytime* to refresh the stickiness. **Note:** Make sure that it is completely dry before using again.

6. *HUG Forever* is intended for a permanently mounted installation! The user accepts responsibility for the placement before and after the installation. *HUG Forever* can be pried off with a firm pull. A thin flat lever (like a flathead screwdriver) can assist in peeling it off the surface.

7. If you need further assistance or have any questions please contact us via our website.



E-Labeling Information

Please follow the instructions to access the e-labeling information from the Mimic App:

1. Press on the settings icon (⚙️) in the upper right corner of the main screen.

2. Press *Regulatory Certification*.

Support
smartmimic.com/contact-us

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

<https://smartmimic.com/california-prop-65/>

Smart Mimic, Mimic GO, Mimic HUG, HUG Anytime, HUG Forever and the logos are the trademarks of Smart Mimic, Inc.

© Copyright 2021 Smart Mimic, Inc. All rights reserved.



353 Sacramento St. Suite 1812
San Francisco, CA, 94111, USA.

SM-HW-BR-GO-02

Layout Version: 2.0.0



Limited Warranty

Smart Mimic provides a limited warranty for the Mimic GO for a period of 1 year from the Purchase Date. Accessory items are warranted for 30 days. For your country's specific warranty information, please visit: <https://smartmimic.com/warranty>

Use and Care

Mimic GO is water-resistant, not waterproof. You can use Mimic GO outside, but avoid direct contact with water. Mimic GO works best between 14° F (-10° C) and 140 °F (60° C)
CHOKING HAZARD- Mimic GO is not a toy. Please keep it out of the reach of young children and pets.

FCC Compliance Statement
FCC ID: 2AXOE-MIMICGO

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by

the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.



- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and all persons. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Canadian Compliance Statement
IC: 26501-MIMICGO

This device contains license-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR

d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

REMARQUE: Cet équipement est conforme aux limites d'exposition aux radiations RSS-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.



Operation Guide

Introduction

Protect your home and your personal belongings anytime, anywhere with Mimic GO. Mimic GO just takes seconds to set up.

Use Mimic GO with the included Mimic HUG to attach it to a door, a window, a gate, and even a garage door. You can easily place Mimic GO on your backpack, your gear, your luggage, or other belongings you want to secure.

Once activated by any movement, such as opening the door or moving your backpack, Mimic GO will notify you via the mobile App and (optional) set off the alarm and warning light.

Mimic GO can even detect human presence and movement. Once activated, whether somebody is stopping by unexpectedly or somebody unwanted is intruding on your space, Mimic GO will notify you via the mobile App (optional) while setting off the alarm and warning light.

What's In The Box

- 1 x Mimic GO (Matte Red)
- 1 x Micro USB Cable
- 2 x Mimic HUG (Permanent and Removable)
- 1 x Magnet for Sliding Door

Senses

Human Motion
Shift of Attached Object
Door Opening
Heat / Cold

Rechargeable

Up to 90 days on single charge

Alerts

App Notifications
Alarm (up to 120dB)
RGB Light (100 Lumen)

Connection

Bluetooth 5 (up to 400ft / 120m)
LoRaWAN (up to 5 miles / 8km)

Size

1.73 x 1.73 x 0.98 in
(44 x 44 x 25 mm)

Weight

0.88 Oz. (25g)