

# EZ-BT™ MODULE ARDUINO EVALUATION BOARD

## CYBT-213043-EVAL



The EZ-BT™ Module Arduino Evaluation Board (CYBT-213043-EVAL) enables you to evaluate and develop applications on the EZ-BT WICED® Module, CYBT-213043-02. CYBT-213043-EVAL can be used as a standalone evaluation kit or can be combined with Arduino-compatible shields.


The CYBT-213043-02 WICED Module is a fully integrated, fully certified, programmable, Bluetooth® Smart Ready module designed to reduce your time-to-market. It measures 12.0 mm x 16.61 mm x 1.70 mm.

For more information, visit:

[www.cypress.com/bluetooth\\_modules](http://www.cypress.com/bluetooth_modules) - EZ-BT Module home page

[www.cypress.com/EZ-Serial](http://www.cypress.com/EZ-Serial) - EZ-Serial Firmware Platform page

[www.cypress.com/Modus](http://www.cypress.com/Modus) - ModusToolbox page



**Figure 1: CYBT-213043-EVAL Top View**


To use CYBT-213043-EVAL:

- 1) Configure the evaluation board headers/switches to the desired settings.
- 2) Connect the evaluation board to a PC via a USB cable.
- 3) Open the ModusToolbox, develop your application, program and test.

**Note:** Recover the CYBT-213043-EVAL before programming. The Arduino-compatible headers (J3/J4/J6/J7) are optional connections, which provide additional I/O connections to the module and allow for other Arduino shields to be used during development.

# EZ-BT™ MODULE ARDUINO EVALUATION BOARD

## CYBT-213043-EVAL



**Figure 2: CYBT-213043-EVAL Bottom View**

- SW1: Reset Switch routed to the XRES connection on the module.
- SW2: Recover Switch routed to the UART\_CTS connection on the module.
- SW3: User-defined switch routed to the P0 connection on the module via J9.
- SW4: Switch connecting HCI UART connections on the module to the host via USB.
- SW5: Switch connecting PUART connections on the module to the host via USB.
- J1: Connection for external interface for direct HCI UART communication.
- J2: To measure module power supply current.
- J3/J4/J6/J7: Arduino-compatible headers used with an Arduino-compatible shield.
- J8: Configures the VDD voltage input to the module as shown in the below table:

J8 Jumper Configuration	VDD Voltage Level
Short 1 & 2	3.3V
Open 1 & 2	1.8V

- J9: Connects the P0 pad on the module to SW3.
- J10: Connects the P27 pad on the module to LED D1.
- J11: Module Power Supply Selection from LDO or external connector.

The EZ-BT CYBT-213043-02 Module supports Bluetooth SIG Mesh, is qualified for the Bluetooth 5.0 specification and is certified for the 2.4-GHz unlicensed frequency range in USA (FCC), Canada (ISED), Europe (CE) and Japan (MIC).

Visit [www.cypress.com/support](http://www.cypress.com/support) for technical support.